

CURSOR TIER 3 SERIES

Industrial application

C87

C87 ENT X - CURSOR 87 TE X

Technical and Repair manual

This publication provides unit and relevant component repair data, specifications, instructions and methodologies.

This publication has been drawn up for qualified and specialised personnel.

Before performing any operation check that the part relevant to the unit on which you must work is available along with all safety devices for accident-prevention, such as, goggles, helmet, gloves, shoes, etc. and hoisting and transporting equipment.

Operations are to be performed by following the indications included here, using the special equipment indicated and assuring proper repair, compliance with schedule and operator's safety requirements.

Each repair must aim to restore operating efficiency and safety in compliance with the FPT provisions.

FPT cannot be held liable for modifications, alterations or other interventions non authorised by FPT on the vehicle and if the unit is warranted the above mentioned interventions will cause its expiration.

FPT is not liable for repairing interventions.

FPT will provide further details required to carry out the interventions and all the instructions that are not included on this publication.

Data included in this publication may not be up-to-date therefore subject to Manufacturer's modifications that can be added at any time for technical or commercial purposes and also to meet new law regulations in other Countries.

If issues on this publication differ from what is actually noticed on the unit, please get in touch with the FPT network before starting any intervention".

It is forbidden to copy this text or any of its parts and all illustrations included.

Produced by:



F2C CURSOR ENGINES

Cursor F2C **Part I**

Cursor engines application G-Drive **Part 2**

Introduction

	Page
PREFACE TO USER'S GUIDELINE MANUAL . .	3
SYMBOLS	3
<input type="checkbox"/> Warnings	3
<input type="checkbox"/> Service operations	3
GENERAL WARNINGS	5
GENERAL WARNINGS ON THE ELECTRIC SYSTEM	7
<input type="checkbox"/> Bonding and screening	8
CONVERSIONS BETWEEN THE MAIN UNITS OF MEASUREMENT OF THE INTERNATIONAL SYSTEM AND MOST USED DERIVED QUANTITIES	9
KEY OF LECTURE OF THE HEADINGS AND FOOTNOTES	10

PREFACE TO USER'S GUIDELINE MANUAL

Manuals for repairs are split into Parts and Sections, each one of which is marked by a numeral; the contents of these sections are indicated in the general table of contents.

The sections dealing with things mechanic introduce the specifications, tightening torque values, tool lists, assembly detaching/reattaching operations, bench overhauling operations, diagnosis procedures and maintenance schedules.

The sections (or parts) of the electric/electronic system include the descriptions of the electric network and the assembly's electronic systems, wiring diagrams, electric features of components, component coding and the diagnosis procedures for the control units peculiar to the electric system.

Section 1 describes the engine illustrating its features and working in general.

Section 2 describes the type of fuel feed.

Section 3 relates to the specific duty and is divided in four separate parts:

1. Mechanical part, related to the engine overhaul, limited to those components with different characteristics based on the relating specific duty.

2. Electrical part, concerning wiring harness, electrical and electronic equipment with different characteristics based on the relating specific duty.

3. Maintenance planning and specific overhaul.

4. Troubleshooting part dedicated to the operators who, being entitled to provide technical assistance, shall have simple and direct instructions to identify the cause of the major inconveniences.

Sections 4 and 5 illustrate the overhaul operations of the engine overhaul on stand and the necessary equipment to execute such operations.

The appendix contains a list of the general safety regulations to be respected by all installation and maintenance engineers in order to prevent serious accidents taking place.

The manual uses proper symbols in its descriptions; the purpose of these symbols is to classify contained information. In particular, there have been defined a set of symbols to classify warnings and a set for assistance operations.

SYMBOLS - Warnings



Danger for persons

Missing or incomplete observance of these prescriptions can cause serious danger for persons' safety.



Danger of serious damage for the assembly

Failure to comply, both fully or in part, with such prescriptions will involve serious damage to the assembly and may sometimes cause the warranty to become null and void.



General danger

It includes the dangers of above described signals.




Environment protection

Moreover, it describes the correct actions to be taken to ensure that the assembly is used in such a way so as to protect the environment as much as possible.

NOTE It indicates an additional explanation for a piece of information.

Service operations

Example



































Ø 1 = housing for connecting rod small end bush

Ø 2 = housing for connecting rod bearings



Tighten to torque

Tighten to torque + angular value

	Removal Disconnection		Intake
	Refitting Connection		Exhaust
	Removal Disassembly		Operation
	Fitting in place Assembly	ϱ	Compression ratio
	Tighten to torque		Tolerance Weight difference
	Tighten to torque + angle value		Rolling torque
	Press or caulk		Rotation
	Regulation Adjustment		Angle Angular value
	Warning Note		Preload
	Visual inspection Fitting position check		Number of revolutions
	Measurement Value to find Check		Temperature
	Equipment		Pressure
	Surface for machining Machine finish	$>$	Oversized Higher than.... Maximum, peak
	Interference Strained assembly	$<$	Undersized Less than.... Minimum
	Thickness Clearance		Selection Classes Oversizing
	Lubrication Damp Grease		Temperature < 0 °C Cold Winter
	Sealant Adhesive		Temperature > 0 °C Hot Summer
	Air bleeding		

GENERAL WARNINGS



Warnings shown cannot be representative of all danger situations possibly occurring. Therefore, it is suggested to contact immediate superiors where a danger situation occurs which is not described.

Use both specific and general-purpose toolings according to the prescriptions contained in respective use and maintenance handbooks. Check use state and suitability of tools not subjected to regular check.

The manual handling of loads must be assessed in advance because it also depends, besides weight, on its size and on the path.

Handling by mechanical means must be with hoisters proper as for weight as well as for shape and volume. Hoisters, ropes and hooks used must contain clear indications on maximum carrying capacity acceptable. The use of said means is compulsorily permitted to authorised personnel only. Stay duly clear of the load, and, anyhow, never under it.

In disassembling operations, always observe provided prescriptions; prevent mechanical parts being taken out from accidentally striking workshop personnel.

Workshop jobs performed in pairs must always be performed in maximum safety; avoid operations which could be dangerous for the co-operator because of lack of visibility or of his/her not correct position.

Keep personnel not authorised to operations clear of working area.

You shall get familiar with the operating and safety instructions for the assembly prior to operating on the latter. Strictly follow all the safety indications found on the assembly.

Do not leave the running assembly unattended when making repairs.

When carrying out work on the assembly lifted off the ground, verify that the assembly is firmly placed on its supporting stands, and that the manual/automatic safety devices have been actuated in the event that the assembly is to be lifted by means of a hoist.

When you have to operate on assemblies powered by natural gas, follow the instructions contained in the document, as well as all the specific safety standards provided for.

Only remove radiator cap when the engine is cold by cautiously unscrewing it in order to let system residual pressure out.

Inflammable fuel and all inflammable fluids and liquids must be handled with care, according to what contained on harmful materials I 2-point cards. Refuelling must be performed outdoors with the engine off, avoiding lit cigarettes, free flames or sparks in order to prevent sudden fires/bursts. Adequately store inflammable, corrosive and polluting fluids and liquids according to what provided by regulations in force. Compulsorily avoid to use food containers to store harmful liquids. Avoid to drill or bore pressurised containers, and throw cloths impregnated with inflammable substances into suitable containers.

Worn out, damaged or consumable parts must be replaced by original spares.

During workshop activity, always keep the work place clean; timely clear or clean floors from accidental liquid or oil spots. Electric sockets and electric equipment necessary to perform repair interventions must meet safety rules.



Put on, where required by the intervention, garments and protections provided in accident prevention rules; contact with moving parts can cause serious injuries. Use suitable, preferably tight-fitted garments, and avoid to use jewels, scarves, etc.

Do not leave the engine in motion at workshop locations not provided with a pipe to scavenge exhaust gas outside.

Avoid to breathe fumes coming from heating or from paint welding because they can cause damages to health; operate outdoors or in suitably ventilated areas. Put on proper inspirator if paint powder is present.

Avoid contact with hot water or steam coming from the engine, radiator and pipings because they could cause serious burns. Avoid direct contact with liquids and fluids present in vehicle systems; where an accidental contact has occurred, refer to 12-point cards for provisions to make.



Clean the assemblies and carefully verify that they are intact prior to overhauling. Tidy up detached or disassembled parts with their securing elements (screws, nuts, etc.) into special containers.

Check for the integrity of the parts which prevent screws from being unscrewed: broken washers, dowels, clips, etc. Self-locking nuts with an insert made of nylon must always be replaced.

Avoid contact of rubber parts with diesel oil, petrol or other not compatible substances.

Before washing under pressure mechanical parts, protect electric connectors, and central units, if present.

Tightening screws and nuts must always be according to prescriptions; FPT commercial and assistance network is available to give all clarifications necessary to perform repair interventions not provided in this document.

Before welding:

- ☐ Disconnect all electronic central units, take power cable off battery positive terminal (connect it to chassis bonding) and detach connectors.
- ☐ Remove paint by using proper solvents or paint removers and clean relevant surfaces with soap and water.
- ☐ Await about 15 minutes before welding.
- ☐ Equip with suitable fire resistant protections to protect hoses or other components where fluids or other materials flow which may catch fire easily on welding.

Should the vehicle be subjected to temperatures exceeding 80°C (dryer ovens), disassemble drive electronic central units.



The disposal of all liquids and fluids must be performed with full observance of specific rules in force.

GENERAL WARNINGS ON THE ELECTRIC SYSTEM



If an intervention has to be made on the electric/electronic system, disconnect batteries from the system; in this case, always disconnect, as a first one, the chassis bonding cable from batteries negative terminal.

Before connecting the batteries to the system, make sure that the system is well isolated.

Disconnect the external recharging apparatus from the public utility network before taking apparatus pins off battery terminals.

Do not cause sparks to be generated in checking if the circuit is energised.

Do not use a test lamp in checking circuit continuity, but only use proper control apparatuses.

Make sure that the electronic devices wiring harnesses (length, lead type, location, strapping, connection to screening braiding, bonding, etc.) comply with FPT system and are carefully recovered after repair or maintenance interventions.

Measurements in drive electronic central units, plugged connections and electric connections to components can only be made on proper testing lines with special plugs and plug bushes. Never use improper means like wires, screwdrivers, clips and the like in order to avoid the danger of causing a short circuit, as well as of damaging plugged connections, which would later cause contact problems.



To start up the engine, do not use fast chargers. Start up must only be performed with either separate batteries or special truck.

A wrong polarisation of supply voltage in drive electronic central units (for instance, a wrong polarisation of batteries) can cause them to be destroyed.

Disconnect the batteries from the system during their recharging with an external apparatus.

On connecting, only screw up connector (temperature sensors, pressure sensors etc.) nuts at prescribed tightening torque.

Before disconnecting the junction connector from an electronic central unit, isolate the system.

Do not directly supply electronic central units servo components at nominal vehicle voltage.

Cables must be arranged such as to result to be parallel to reference plane, i.e. as close as possible to chassis/body structure.

Once the intervention on the electric system has been completed, recover connectors and wiring harnesses according to original arrangement.

NOTE Connectors present must be seen from cable side. Connectors views contained in the manual are representative of cable side.


Bonding and screening

Negative leads connected to a system bonded point must be both as short and possible and "star"-connected to each other, trying then to have their centering tidily and properly made (Figure 1, re. M).

Further, following warnings are to be compulsorily observed for electronic components:


- Electronic central units must be connected to system bonding when they are provided with a metallic shell.
- Electronic central units negative cables must be connected both to a system bonding point such as the dashboard opening bonding (avoiding "serial" or "chain" connections), and to battery negative terminal.
- Analog bonding (sensors), although not connected to battery negative system/terminal bonding, must have optimal isolation. Consequently, particularly considered must be parasitic resistances in lugs: oxidising, clinching defects, etc.
- Screened circuits braiding must only electrically contact the end towards the central unit entered by the signal (Figure 2).
- If junction connectors are present, unscreened section **d**, near them, must be as short as possible (Figure 2).
- Cables must be arranged such as to result to be parallel to reference plane, i.e. as close as possible to chassis/body structure.

Figure 1



1. NEGATIVE CABLES "STAR" CONNECTION TO SYSTEM BONDING M

Figure 2



88039

2. SCREENING THROUGH METALLIC BRAIDING OF A CABLE TO AN ELECTRONIC COMPONENT – C. CONNECTOR
d. DISTANCE → 0

CONVERSIONS BETWEEN THE MAIN UNITS OF MEASUREMENT OF THE INTERNATIONAL SYSTEM AND MOST USED DERIVED QUANTITIES

Power

1 kW	=	1.36 metric HP
1 kW	=	1.34 HP
1 metric HP	=	0.736 kW
1 metric HP	=	0.986 HP
1 HP	=	0.746 kW
1 HP	=	1.014 metric HP

Torque

1 Nm	=	0.1019 kgm
1 kgm	=	9.81 Nm

Revolutions per time unit

1 rad/s	=	1 rpm \times 0.1046
1 rpm	=	1 rad/s \times 9.5602

Pressure

1 bar	=	1.02 kg/cm ²
1 kg/cm ²	=	0.981 bar
1 bar	=	10 ⁵ Pa

Where accuracy is not particularly needed:

☐ Nm unit is for the sake of simplicity converted into kgm according to ratio 10:1

1 kgm = 10 Nm;

☐ bar unit is for the sake of simplicity converted into kg/cm² according to ratio 1:1






1 kg/cm² = 1 bar.

Temperature

0° C = 32° F

1° C = (1 \times 1.8 + 32) ° F

KEY OF LECTURE OF THE HEADINGS AND FOOTNOTES

Type of vehicle	Section title	Page number
MOTORI NEF F4HE	SEZIONE 4 - REVISIONE MECCANICA GENERALE	11
	<p>REVISIONE MOTORE 4 E 6 CIL. SMONTAGGIO DEL MOTORE AL BANCO</p> <p>La trattazione seguente prevede che il motore sia stato montato sul cavalletto rotativo e si sia proceduto alla rimozione di tutti i componenti specifici dell'applicazione Iveco Motors (vedere la Sezione 3 del presente manuale).</p> <p>La sezione riguarda quindi tutte le più importanti procedure di revisione del basamento motore.</p> <p>Le operazioni seguenti riguardano il motore 4 cilindri, ma risultano analoghe per il 6 cilindri.</p> <p>Figura 1</p>  <p>70158</p> <p>SVITARE LE VITI DI FISSAGGIO (1) E RIMUOVERE I CAPPELLI DI BIELLA (2). Sfilare gli stantuffi completi di bielle dalla parte superiore del basamento.</p> <p>NOTA Mantenere i semicuscini nei rispettivi alloggiamenti, poiché, in caso di un loro utilizzo, dovranno essere montati nella posizione riscontrata allo smontaggio.</p> <p>Figura 2</p>  <p>70199</p> <p>Rimuovere le viti (1) e smontare i cappelli di banco (2).</p> <p>Figura 3</p>  <p>70160</p> <p>Il penultimo cappello di banco (1) e il relativo supporto hanno il semicuscinetto (2) dotato di spallamento.</p> <p>NOTA Le viti M12 dei cappelli di banco, devono essere sostituite se il diametro nominale della parte filettata che non lavora, presenta un diametro < 0,1 mm rispetto al valore nominale.</p> <p>NOTA Annotare la posizione di montaggio dei semicuscini inferiori e superiori, poiché in caso di un loro riutilizzo, dovranno essere montati nella posizione riscontrata allo smontaggio.</p> <p>Figura 4</p>  <p>70161</p> <p>Con l'attrezzo 99360500 (1) e sollevatore rimuovere l'albero motore (2) dal basamento.</p> <p>Figura 5</p>  <p>70162</p> <p>Smontare i semicuscini di banco (1). Rimuovere le viti (2) e smontare gli spruzzatori olio (3).</p>	
Print P2D32N003.1		
Printout number	Language Publication	
	Basic edition referred to month - year editorial phase closing	When month - year update is present (revi) to the basic edition

Part I	
F2C CURSOR ENGINES	Section
General specifications	I
Fuel	2
Industrial application	3
Overhaul and technical specifications	4
Tools	5
Safety prescriptions	Appendix

UPDATING


Section	Description	Page	Date of revision

SECTION I**General Specifications**

	Page
MAPPING BETWEEN TECHNICAL AND COMMERCIAL CODING	3
VIEWS OF THE ENGINE	5
LUBRICATION DIAGRAM	8
<input type="checkbox"/> Oil pump	9
<input type="checkbox"/> Overpressure valve	9
<input type="checkbox"/> Oil pressure control valve	10
<input type="checkbox"/> Heat exchanger	10
ENGINE OIL FILTER	11
<input type="checkbox"/> Characteristics	11
<input type="checkbox"/> Lock torques	11
<input type="checkbox"/> Installation rule	11
<input type="checkbox"/> Filter by-pass valve	11
<input type="checkbox"/> Replacing oil filter cartridge	12
<input type="checkbox"/> Oil fume recycle (Blow-by)	13
COOLING	14
<input type="checkbox"/> Description	14
<input type="checkbox"/> Operation	14
<input type="checkbox"/> Water pump	16
<input type="checkbox"/> Thermostat	16
TURBOCHARGING	17
EGR EXHAUST GAS RECYCLE SYSTEM	18
INTERNAL EGR OPERATING ON SUCTION VALVES	18


MAPPING BETWEEN TECHNICAL AND COMMERCIAL CODING

Technical Code	Commercial Code
F2CE9687A*E00I F2CE9687B*E00I F2CE9687C*E00I	C87 ENT X

VIEWS OF THE ENGINE**Figure 1**

144838


LEFT-HAND SIDE VIEW

Figure 2

144839

RIGHT-HAND SIDE VIEW


Figure 3



144840

FRONT HAND SIDE VIEW


Figure 4



144841


REAR HAND SIDE VIEW

Figure 5




I44842

TOP VIEW

LUBRICATION DIAGRAM**Figure 6**


■ Dropping oil
■ Pressure oil

114244

Oil pump**Figure 7**



The oil pump (1) cannot be overhauled. On finding any damage, replace the oil pump assembly.

See under the relevant heading for replacing the gear (2) of the crankshaft.

Overpressure valve**Figure 9**

117716


MAIN DATA TO CHECK THE OVERPRESSURE VALVE SPRING

Figure 8

112327


OIL PUMP CROSS-SECTION

1. Overpressure valve – Start of opening pressure 10.1 ± 0.7 bars.

Oil pressure control valve**Figure 10**


73542

The oil pressure control valve is located on the left-hand side of the crankcase.
Start of opening pressure 5 bars.

Figure 11

88819

MAIN DATA TO CHECK THE OIL PRESSURE
CONTROL VALVE SPRING


Heat exchanger**Figure 12**

114246

1. Exchanger seal - 2. Internal heat exchanger element - 3. Cover - 4. Oil filter - 5. Oil filter seal

ENGINE OIL FILTER

Figure 13



1. Closure cap - 2. Cartridge - 3. Spring - 4. Support O-ring - 5. Tank O-ring - 6. Washer - 7. Washer - 8. Support - 9. Plug M14x1.5 - 10. Plug M38x1.5 - 11. By-pass valve 3.4 bars.

Characteristics

1. Max working pressure: 13 bars
2. Working temperature: $-30^{\circ}\text{C} \div +120^{\circ}\text{C}$
3. By-pass valve opening value: $3,4 \pm 0,3$ bar

Lock torques


Cap (part 1):	60 ± 5 Nm
Plug (part 9):	30 ± 5 Nm
Plug (part 10):	90 ± 5 Nm

Installation rule

Use threadlock for plug (part 10).

Filter by-pass valve

Figure 14




Valve opens quickly at $3,4 \pm 0,3$ bar pressure.

Replacing oil filter cartridge

Dismantling

Figure 15



Remove the plug (2).


Undo the filter casing (1) by a couple of turns and wait for a few minutes.

In this way the remaining oil in the casing starts firstly to drip and then to flow smoothly out.

Completely undo the casing and then replace the cartridge.

Refitting

Figure 16




Insert the cartridge in the casing aligning the centering tabs (2) on the upper plate (1) with the seats.

The cartridge should be pushed into the container until the action of the attachment system at the bottom of the casing is overcome.

At the same time, the tabs on the upper plate should slide into the housings.

Figure 17




Move the upper part of the casing thread close to the first lower thread of the support (the cartridge cover element should be in contact with the oil outlet duct on the support).

Proceed with tightening the cartridge-casing assembly (1) on the support (4).

During this stage both the seal (3) for the oil outlet duct-cartridge element and the casing-support seal (2) will gradually be involved.

Tighten the filter casing to a torque of 65 Nm.

Figure 18



Tighten the protective cap (1) on the filter casing.


Oil fume recycle (Blow-by)

Part of gas produced by combustion during engine operation leaks through piston elastic ring openings into sump, mixing with oil fumes in sump.

This mixture, conveyed upward, is partially separated from oil by a device located in timing cover upper part and introduced in air intake circuit.

The device mainly consists of a rotary filter secured on propeller shaft and by a front cover housing normally closed valves controlling mixture flow.

Figure 19



COOLING

Description

The engine cooling system is of the closed-circuit, forced circulation type. It consists mainly of the following components:


- ☐ expansion tank, not supplied (by IVECO);
- ☐ a heat exchanger to cool down lubrication oil;
- ☐ a water pump with centrifugal system incorporated in the cylinder block;
- ☐ fan, not supplied;
- ☐ a 2-way thermostat controlling the coolant circulation.




Operation

The water pump is actuated by the crankshaft through a poli-V belt and sends coolant to the cylinder block, especially to the cylinder head (bigger quantity). When the coolant temperature reaches and overcomes the operating temperature, the thermostat is opened and from here the coolant flows into the radiator and is cooled down by the fan.

The pressure inside the system, due to temperature change, is adequately controlled through the expansion vessel.

Figure 20




-  Water flowing out of the thermostat
-  Water circulating in the engine
-  Water flowing into the pump

114249

Water pump

Figure 21



144832

CROSS-SECTION OF THE WATER PUMP


The water pump comprises: impeller, shaft with bearing, front seal, drive pulley.

NOTE Check that the pump body has no cracks or water leakage; if it does, replace the entire water pump.

Thermostat

View of thermostat operation


Figure 22



45357

Water circulating in the engine

Figure 23



45358

Water leaving the thermostat

Check the thermostat works properly; replace it if in doubt.

Temperature of start of travel $85^{\circ}\text{C} \pm 1.5^{\circ}\text{C}$.



Minimum travel 9.5 mm at 95°C .

TURBOCHARGING

The turbocharging system consists of:

- ☐ air filter;
- ☐ Wastegate turbocharger.

Figure 24



114251

EGR EXHAUST GAS RECYCLE SYSTEM

The exhaust gas can be partially recycled to cylinders to reduce maximum temperature values of combustion that produce nitrogen oxides (NO_x).

The exhaust gas recycle system (EGR) reduces combustion temperature and therefore is an efficient NO_x emission control system.


INTERNAL EGR OPERATING ON SUCTION VALVES

The specific design of suction cams of the internal EGR system allows part of exhaust gas to be recycled to engine cylinders.

This type of EGR, called internal EGR, is not equipped with any electronic control, the system is always active. Its configuration requires no additional parts such as control valves, pipelines or heat exchangers therefore engine profile remains unchanged.

Besides main lobe, suction cam has an additional lobe (3) as to configuration without EGR. During concerned cylinder exhaust phase, this lobe allows a shaft advanced opening of intake valve (*). In this way, part of the exhaust gas is trapped in the suction duct and later, during cylinder suction phase, this gas is recycled to cylinder inlet for combustion phase.

Figure 25



114026

I. Exhaust cams - 2. Suction cams - 3. EGR lobe - S. Exhaust ducts - A. Intake ducts

SECTION 2**Fuel**

	Page
SUPPLY	3
FUEL SUPPLY DIAGRAM	4
MECHANICAL SUPPLY PUMP	5
<input type="checkbox"/> Normal operating conditions	5
<input type="checkbox"/> Overpressure condition at outlet	5
<input type="checkbox"/> Drain conditions	5
CP3 HIGH-PRESSURE PUMP	6
HIGH-PRESSURE PUMP - INSIDE STRUCTURE ..	7
<input type="checkbox"/> Operating principle	8
<input type="checkbox"/> Operation	10
RAIL (PRESSURE ACCUMULATOR)	10
<input type="checkbox"/> Electroinjector	10


SUPPLY

The Common Rail supply system is equipped with a special pump that maintains fuel at constant high pressure regardless from phase and cylinder under injection and accumulated in a common duct shared by all electric injectors.

Therefore, fuel at injection pressure, calculated by ECU, is always available at electric injection inlet.

When the solenoid valve of an injector is energized by ECU, in related cylinder the injection of fuel taken directly from the rail takes place.

Figure I




MECHANICAL SUPPLY PUMP

Gear pump, fitted on the rear side of the high pressure pump and used to supply it.

It is controlled by high pressure pump shaft.

Normal operating conditions

Figure 3




72592

A Fuel inlet from tank, B fuel outlet to filter, 1-2 by-pass valves in close position

Overpressure condition at outlet

Figure 4




72593

The by-pass valve (1) cuts in when overpressure is generated at outlet B. The existing pressure, overcoming valve spring (1) elastic strength, makes inlet and outlet communicating through duct (2).

Drain conditions

Figure 5



72594

The by-pass valve (2) cuts in when, with engine off, the fuel system shall be filled through the priming pump. In this situation the by-pass valve (1) stays closed whereas by-pass valve (2) opens due to inlet pressure, and fuel is drained out through B.

NOTE The mechanical supply pump cannot be replaced individually, therefore it cannot be removed from the high pressure pump.

CP3 HIGH-PRESSURE PUMP


Pump with 3 radial pistons controlled by the timing gear, without needing any setting. On the rear side of the high pressure pump is fitted the mechanical supply pump controlled by the high pressure pump shaft.



The following work must be carried out on the feed pump / high-pressure pump assembly:

- ☐ replacing the drive gear;
- ☐ replacing the pressure regulator.

Figure 6




72595

1. Fuel outlet fitting to rail - 2. High-pressure pump - 3. Pressure regulator - 4. Control gear - 5. Fuel inlet fitting from filter - 6. Fuel outlet fitting to filter support - 7. Fuel inlet fitting from control unit heat exchanger - 8. Fuel outlet fitting from supply pump to filter - 9. Mechanical supply pump

HIGH-PRESSURE PUMP - INSIDE STRUCTURE

Figure 7



70498

1. Cylinder – 2. Three-lobe element – 3. Cap intake valve – 4. Ball delivery valve – 5. Piston – 6. Pump shaft –
7. Low-pressure fuel inlet – 8. Pumping elements supplying fuel ducts

Every pumping unit is composed of:


- ☐ a piston (5) actuated by a three-lobe element (2) floating on the pump shaft (6). The element (2), being **floating** on a misaligned part of the shaft (6), when the shaft rotates, does not rotate therewith but is only

translated in a circular movement along a wider radius, with the resulting alternate actuation of the three pumping elements;


- ☐ cap intake valve (3);
- ☐ ball delivery valve (4).

Operating principle

Figure 8



Sec. B – B



Sec. D – D


72597

1. Fuel outlet fitting to rail - 2. Delivery valve to rail - 3. Pumping element - 4. Pump shaft - 5. Pumping element supply duct - 6. Pressure regulator supply duct - 7. Pressure regulator

Pumping element (3) is oriented to pump shaft (4) cam. During intake, the pumping element is supplied through supply duct (5). The fuel amount to be sent to the pumping element is set by the pressure regulator (7). The pressure regulator meters fuel flow to pumping element according to

the PWM signal received from ECU. During pumping element compression stage, fuel reaches the pressure required to open the delivery valve to common rail (2) and to feed it through outlet (1).

Figure 9



Sec. C – C

72598

1. Pumping element inlet - 2. Pump lubrication ducts -
3. Pumping element inlet - 4. Main pumping element
supply duct - 5. Pressure regulator - 6. Pumping element
inlet - 7. Regulator exhaust duct - 8. 5 bar pressure relief
valve - 9. Fuel drain from regulator inlet


Figure 9 shows low pressure fuel paths inside the path and highlights: main pumping element supply duct (4), pumping element supply ducts (1 – 3 – 6), pump lubrication ducts (2), pressure regulator (5), 5 bar pressure relief valve (8) and fuel drain duct (7).

Pump shaft is lubricated by fuel through delivery and return ducts (2).

Pressure regulator (5) establishes the fuel amount to send to pumping elements; excess fuel is drained out through duct (9).

5 bar pressure relief valve acts as fuel exhaust manifold and keeps 5 bar constant pressure at regulator inlet.

Figure 10



Sec. A – A

72601

1. Fuel outlet duct - 2. Fuel outlet duct - 3. Fuel outlet
from pump with high pressure pipe fitting for common rail

Figure 10 shows high pressure fuel flow through pumping element outlet ducts.

Operation

The cylinder is filled through the cap intake valve only if the supply pressure is suitable to open the delivery valves set on the pumping elements (about 2 bars).

The amount of fuel supplying the high-pressure pump is metered by the pressure regulator, placed on the low-pressure system; the pressure regulator is controlled by the EDC7 control unit through a PWM signal.

When fuel is sent to a pumping element, the related piston is moving downwards (suction stroke). When the piston stroke is reversed, the intake valve closes and the remaining fuel in the pumping element chamber, not being able to come out, is compressed above the supply pressure value existing in the rail.

The thereby-generated pressure makes the exhaust valve open and the compressed fuel reaches the high-pressure circuit.

The pumping element compresses the fuel till the top dead center (delivery stroke) is reached. Afterwards, the pressure decreases till the exhaust valve is closed.

The pumping element piston goes back towards the bottom dead center and the remaining fuel is decompressed.

When the pumping element chamber pressure becomes less than the supply pressure, the intake valve is again opened and the cycle is repeated.

The delivery valves must always be free in their movements, free from impurities and oxidation.

The rail delivery pressure is modulated by the electronic control unit, through the pressure regulator solenoid valve.


The pump is lubricated and cooled by the fuel.

The radialjet pump disconnection – reconnection time on the engine is highly reduced in comparison with traditional injection pumps, because it does not require setting.

If the pipe between fuel filter and high-pressure pump is to be removed-refitted, be sure that hands and components are absolutely clean.

RAIL (PRESSURE ACCUMULATOR)

Figure 11



144833

1. Rail - 2. Fuel return - 3. Pipelines to injectors - 4. Fuel supply to high pressure pump - 5. Pressure sensor - 6. Overpressure valve


The rail volume is of reduced sizes to allow a quick pressurisation at startup, at idle and in case of high flow-rates.

It anyway has enough volume as to minimise use of plenum chambers caused by injectors openings and closings and by the high-pressure pump operation. This function is further enabled by a calibrated hole being set downstream of the high-pressure pump.

A fuel pressure sensor (5) is screwed to the rail. The signal sent by this sensor to the electronic control unit is a feed-back information, depending on which the rail pressure value is checked and, if necessary, corrected.

Electroinjector

Figure 12



114255














1. Fuel return hole - 2. Fuel supply

SECTION 3**Industrial application**

	Page
CLEARANCE DATA	3
PART ONE - MECHANICAL COMPONENTS	5
ENGINE DISASSEMBLY ON BENCH	7
ASSEMBLY	11
<input type="checkbox"/> High pressure pump installation	15
ENGINE FLYWHEEL	15
<input type="checkbox"/> Engine flywheel installation	15
<input type="checkbox"/> Camshaft installation	16
TIMING CAMSHAFT AND FLYWHEEL USING TOOL 99395223	17
<input type="checkbox"/> Timing camshaft	17
<input type="checkbox"/> Timing flywheel	19
TIMING CAMSHAFT AND FLYWHEEL WITHOUT TOOL 99395223	19
<input type="checkbox"/> Timing camshaft	19
<input type="checkbox"/> Timing flywheel	22
<input type="checkbox"/> Intake and exhaust rocker arm clearance adjustment	23
ENGINE ASSEMBLY COMPLETION	25
PART TWO - ELECTRICAL EQUIPMENT	27
COMPONENTS ON THE ENGINE F2C	29
ENGINE CABLE	30
EDC 7 UC3I CONTROL UNIT PIN-OUT	31
EDC 7 UC3I ELECTRONIC CONTROL UNIT ..	32
EDC CONTROL UNIT PIN-OUT	33
<input type="checkbox"/> Electric injector connector "A"	33
<input type="checkbox"/> Sensor connector "C"	34
<input type="checkbox"/> Electroinjectors	35
<input type="checkbox"/> Engine coolant temperature sensor	36
<input type="checkbox"/> Fuel temperature sensor	37

	Page
<input type="checkbox"/> High pressure pump (pressure regulator)	38
<input type="checkbox"/> Flywheel pulse transmitter	39
<input type="checkbox"/> Distribution pulse transmitter	40
<input type="checkbox"/> Oil temperature/pressure sensor (42030 /47032)	41
<input type="checkbox"/> Air pressure/temperature sensor (85156) . . .	42
<input type="checkbox"/> Fuel pressure sensor on rail	43
<input type="checkbox"/> Alternator	44
<input type="checkbox"/> Starting motor	45
EDC SYSTEM FUNCTIONS	46
PART THREE - TROUBLESHOOTING	49
PREFACE	51
DIAGNOSTIC EQUIPMENT	52
<input type="checkbox"/> PT-01	52
<input type="checkbox"/> PT - BOX	53
FAULT CODES	54
PART FOUR - MAINTENANCE PLANNING	57
MAINTENANCE PLANNING	59
<input type="checkbox"/> Recovery	59
<input type="checkbox"/> Planning of controls and periodical intervention	59
OFF-PLANE OPERATIONS	61
MAINTENANCE PROCEDURES	62
<input type="checkbox"/> Checks and controls	62

CLEARANCE DATA

 <div>Type</div>	F2CE9687		
	A*E	B*E	C*E
 <div>Cycle</div> <div>Fuel feed</div> <div>Injection</div>	4-stroke Diesel engine		
	Turbocharged		
	Direct		
 <div>No. of cylinders</div>	6 in line		
 <div>Bore</div> <div>mm</div>	117		
 <div>Stroke</div> <div>mm</div>	135		
 <div>Total displacement</div> <div>cm³</div>	8710		
 <div>Compression ratio</div>	1: 15.9 ± 0.8		
 <div>Maximum power</div> <div>kW (CV) rpm</div>	260 354 2100	230 313 2100	200 272 2100
 <div>Max. torque</div> <div>Nm (kgm) rpm</div>	1500 1400	1400 1400	1300 1400
 <div>Loadless engine idling</div> <div>rpm</div>	-		
 <div>Loadless engine peak</div> <div>rpm</div>	-		
 <div>SUPERCHARGING</div> <div>Turbocharger type</div>	Intercooler Direct injection HX40		
 <div>LUBRICATION</div> <div>Oil pressure (warm engine)</div> <div>- idling</div> <div>- peak rpm</div> <div>bar</div> <div>bar</div>	Forced by gear pump, relief valve single action oil filter - -		
<div>COOLING</div> <div>Water pump control</div> <div>Thermostat</div> <div>- start of opening</div> <div>°C</div>	Liquid Through belt 85		

NOTE Data, features and performances are valid only if the setter fully complies with all the installation prescriptions provided by FPT.

Furthermore, the users assembled by the setter shall always be in conformance to couple, power and number of turns based on which the engine has been designed.


**PART ONE -
MECHANICAL COMPONENTS**

ENGINE DISASSEMBLY ON BENCH

NOTE Before installing engine on rotary stand 99322230, remove parts that might interfere with the installation of brackets 99361042.

Therefore, remove heat exchanger and oil line as shown below.

Figure 1



Under heat exchanger (2) place a container for engine coolant drain.


Unlock retaining screws and remove heat exchanger assembly (2).

Remove oil outlet line (1).

Install engine on rotary stand 99322230.

Drain sump oil in specific container.


Figure 2



Unlock retaining screws (2) and remove head cover (1) to reach injector and rail wiring.

Remove wiring from all components shown in "Electric equipment" section.

Figure 3




114007

If air conditioner compressor is installed, cut belt (2) as it must not be reused.

Use specific tool (1) and operate in the arrow direction to remove water pump and alternator control belt (5).

Remove screws and separate pulleys (3) and (6) with damping flywheel (4).

Figure 4




114008

Remove parts below:


- ☐ alternator (1);
- ☐ belt tensioner (2);
- ☐ if present, air conditioner compressor (3);
- ☐ water pump (6);
- ☐ flanged pipe (4);
- ☐ fixed belt tensioner (5);
- ☐ thermostat assembly (7).

Figure 5



Apply extractor 99340051 (2) and remove seal (1).
Unlock screws and remove front cover (3).

Figure 6




Remove parts below:

- ☐ oil filter (1);
- ☐ oil inlet line (2);
- ☐ turbocompressor (4) and exhaust manifold (3).

On opposite engine side, remove start-up motor.


Figure 7



Remove parts below:


- ☐ fuel filter (3);
- ☐ oil level rod (2);
- ☐ intake manifold (1).

Figure 8




Disconnect line (1) from high pressure pump support and remove ECU (2) with support below.

Figure 9




Remove screws (1) and blow-by box (2).

Figure 10



Unlock screws (2) and remove cover (1). Remove centrifugal filter (3) below.

Figure 11




Use specific spanner to unlock screws (2) and remove gear (3) complete with tune wheel.

Unlock nut (4) and remove control gear (5) of high pressure pump.

Remove rpm sensor (1).


NOTE In case removal of gear (5) is difficult, release high pressure pump screws with light beater strokes on control shaft and remove gear (5).

Figure 12



Disconnect fuel lines (2), unlock retaining screws and remove high pressure pump (1). Remove fuel filter support (3) complete with pipeline.

Figure 13




Unlock screws (1) and remove thrust plate (2).

Use specific spanner to unlock screws (4) and remove relay gear (5).


Remove high pressure pump mount flange (3).

Figure 14




Use specific tool lock engine flywheel (2) rotation, unlock retaining screws (1) and remove engine flywheel.

Figure 15




Apply extractor 99340054 (2) and remove seal (1).

Figure 16




Unlock screws (1) and remove engine oil sump (3) complete with spacer (2) and seal.

Figure 17




Unlock screws and remove suction rose (1).

Figure 18



Unlock screws (1) and remove flywheel box (2).

Figure 19




Remove screws (2) and double gear (3).

Remove retaining screw (5) and connecting rod (4).

Remove oil pump (1).


Figure 20



☐ Unlock rocker arm shaft retaining screws (4).


☐ Disconnect fuel pipelines (1) from injector rail, fuel supply line (2) of high pressure pump to rail and return line (3).

Figure 21




Apply tool 99360558 (1) to rocker arm shaft (2) and remove shaft, remove crosspieces (3) from cylinder head.

Figure 22





Remove retaining brackets (3) and remove injectors (4).
Remove retaining screws (1) and remove rail (2).

Figure 23



Remove camshaft and remove cylinder head retaining screws.
Use metallic ropes to lift cylinder head (1) and remove seal (2).

Figure 24



Clean the surface of the parts to be joined removing impurities and oil residuals. Apply silicon LOCTITE 275 (1) to the cover (2) as shown in the picture.


The diameter of the sealing string must be $1.5 \pm 0.5/0.2$.



Fit the front cover within 10 minutes after applying the sealer.


ASSEMBLY

Figure 25



Install front cover (1) and lock retaining screw at required torque.


Figure 26



114258

Secure seal (1), install special tool 99346260 (2), lock nut (3) to secure seal (1).

Figure 27




42566

Check that pistons 1-6 are exactly at T.D.C. Place seal (2) on cylinder block. Install cylinder head (1) and lock screws as shown in figures below.



Removed screws must not be used again. Employ new screws only.


Figure 28



114259

Cylinder head retaining screw locking sequence diagram.


Figure 29



45267

- Pre-lock by torque wrench (1):
1st phase: 50 Nm (5 kgm);
2nd phase: 100 Nm (10 kgm).


Figure 30



45268

- Angle locking by means of tool 99395216 (1):
3rd phase: 90° angle
4th phase: 75° angle.


Figure 31



145833

- Install oil pump (1), double gear (3) complete with connecting rod (4) and lock screws (2) in two phases:
pre-lock 30 Nm
90° angle lock

Figure 32



114260



The previously removed pipes can no longer be refit and must be replaced.



Lubricate the injector fastening O-Rings using the following lubricants: PDE SILIKONFETT 22, NLG 12, PDE LUBRICOMET GR 220 NLG 12.

1. Install rail on cylinder head and lock retaining screws by hand.
2. Install injectors in correct position and lock to required torque.



Check that the injectors (2) are equidistant from the springs (I). Distance "X" which separates them should always be the same.

3. Install pipes on rail and lock fittings by hand.
4. Lock rail to cylinder head retaining screws at required torque.


5. Fit pipes on injectors and head locking fittings by hand.
6. Lock fittings on rail (A, C) at required torque.
7. Lock fittings on injectors and head (B, C) at required torque.

TYPE	DESCRIPTION	LOCK TORQUE
A	M18 x 1.5	40 ± 2 Nm
B	M14 x 1.5	35 ± 2 Nm
C	M16 x 1.5	40 ± 2 Nm



After fitting the high-pressure pipelines, during the following 20 hours of work, frequently check engine oil level (IT MUST NOT INCREASE).

Figure 33




Clean surfaces to be coupled to remove dirt and oil residuals. Apply LOCTITE 275 (2) silicone on gear casing (1) as shown in the figure.

The sealant seam diameter must be $1.5 \pm 0.5/0.2$ mm.




Install gear casing within 10 min. from sealant application.

Figure 34



Use torque wrench to lock screws (1) at required torque.

Figure 35




Clean surfaces to be coupled to remove dirt and oil residuals. Apply LOCTITE 275 silicone on gear casing (1) as shown in the figure.

The sealant seam diameter must be $1.5 \pm 0.5/0.2$ mm.



Install gear casing within 10 min. from sealant application.

Figure 36




Apply gage 99395221 (1) to check and adjust position of high-pressure pump connection flange (2).

Fix flange screws (2) at required torque.

High pressure pump installation

Figure 37




Install high-pressure pump (1) on flange (2).

ENGINE FLYWHEEL

NOTE If toothing on engine flywheel for engine start-up is very damaged, change crown wheel.

Refit crown wheel after heating up at approx. 200°C.

Figure 38




Secure seal (1), install special tool 99346260 (2), lock nut (3) to secure seal.

Engine flywheel installation

NOTE Crankshaft has a reference pin that must match with related housing on engine flywheel.


Figure 39



DETAIL OF PISTON POSITION STAMPING ON ENGINE FLYWHEEL

A. Hole on flywheel with a notch corresponding to pistons 3-4 TDC - B. Hole on flywheel with a notch, corresponding to piston 1-6 TDC - C. Hole on flywheel with a notch corresponding to pistons 2-5 TDC - D. Hole on flywheel with 2 notches, position corresponding to 54°.

Figure 40




Position flywheel (1) on crankshaft, lubricate screws (2) threading with engine oil and lock them.

Stop rotation using specific tool.

Lock screws (2) in three phases.

1st phase: pre-lock with torque wrench (3) at 100 Nm torque (10 kgm).


Figure 41



2nd phase: 60° angle locking using tool 99395216 (1).

Camshaft installation

Figure 42



Position crankshaft with pistons 1 and 6 at TDC.


This condition is obtained when:

1. the opening with one reference (5) for the engine flywheel (4) is visible from the inspection window;
2. tool 99360612 (1), through housing (2) of engine rpm sensor, inserts in hole (3) drilled on engine flywheel (4).

Otherwise, adjust engine flywheel orientation (4).

Remove tool 99360612 (1).

Figure 43



Install camshaft (3) and orient it with references (→) positioned as in the figure.

Clean the matching surfaces of the plate (1) to remove impurities and oil residues.


Apply silicon LOCTITE 275 (6) on the plate (1) as shown in the picture.

NOTE Take care NOT to get sealant on the inner groove (5).

The diameter of the sealant bead should be 1.5 - 0.5/0.2 mm.

Fit the plate (1) within 10 mins of applying the sealant with the gasket (2) and tighten the bolts (4) to the recommended torque.


Figure 44



114269

Apply gage 99395222 (1), check and adjust position of connecting rod (3) for relay gear, lock screw (2) at required torque.

Figure 45



114270


Refit relay gear (2) and lock screws (1) using six-splined spanner at required torque.

NOTE The relay gear (2) bushing can be replaced when worn out. After securing bushing, grind it to reach dia. 58.010 ± 0.10 mm.

TIMING CAMSHAFT AND FLYWHEEL USING TOOL 99395223

Timing camshaft

Figure 46




115064

Rotate the crankshaft with the tool 99360341 (3, Figure 53) so that the opening marked with two references (5) is visible from the lower inspection window in the flywheel cover casing.

In this condition, insert the tool 99360612 (1) via the housing (2) for the engine rpm sensor in the opening (3) in the engine flywheel (4).


Figure 47



116052


Fit the tool 99395223 (1) at the front of the camshaft.

Figure 48



Rotate the tool (1) 99395223 in order to insert the pin (3) in the opening (2, Figure 47) in the head. Fasten the tool (1) 99395223 using two M8x1.25 bolts (2).

Figure 49




Fit the camshaft drive gear (1) so that the fastening openings in the shaft are aligned with the slots (2) in the drive gear.

Position the gear (1) taking care to position the spokes (4) as illustrated. This operation is necessary in order to be able to fit the flywheel correctly which can only be fitted in one position in relation to the gear.

Tighten the fixing bolts (3).


Figure 50



Install crosspieces (1) on valve rod.

NOTE Before refitting rocker arm shaft assembly, check that all adjustment screws have been fully unlocked.

Figure 51




Apply tool 99360558 (1) to rocker arm shaft (2) and install shaft on cylinder head.

Lock retaining screws at required torque.

Timing flywheel

Figure 52



Fit the high pressure pump gear (5) tightening the nut (4) to torque.

Use the flat washer (PN 17095914) in conjunction with the nut (4) replacing the one supplied with the Bosch CP3 pump.

Fit the flywheel (6) so that the toothe marked with the arrow (→) is in line with the sensor housing (2).

To check that the position is correct, insert tool (1) 99360613 in the timing sensor (2) housing.


Proceed with tightening the bolts (3).

Remove the tools 99395223, 99360612 and 99360613.

TIMING CAMSHAFT AND FLYWHEEL WITHOUT TOOL 99395223

Timing camshaft

Figure 53




Secure special tool 99360341 (3) to gear casing.

NOTE The arrow indicated engine rotation direction.

Use tool above to rotate engine flywheel (1) in engine rotation direction to bring cylinder I piston approx. to TDC in blast phase.

This condition is reached when hole with notch (4), following hole with two notches (5) drilled on engine flywheel (1), is visible through manhole (2).


Figure 54



The exact position of piston no.1 at TDC is obtained when, in conditions described above, tool 99360612 (1), through engine rpm sensor housing (2), inserts in hole (3) drilled on engine flywheel (4).

Otherwise, rotate engine flywheel (4) to adjust its orientation.


Figure 55



115063

Rotate the camshaft so that the openings at the rear of the engine are arranged in the configuration illustrated in the diagram.

Figure 56



117691


Install gear (1) controlling camshaft so that fastening holes on shaft coincide with slots (2) on control gear.

NOTE Position the gear (1) taking care to position the spokes (4) as illustrated.

This operation is necessary in order to be able to fit the flywheel correctly which can only be fitted in one position in relation to the gear.

Lock retaining screws (3).

Figure 57




114276

Install crosspieces (1) on valve rod.

NOTE Before refitting rocker arm shaft assembly, check that all adjustment screws have been fully unlocked.

Figure 58




114025

Apply tool 99360558 (1) to rocker arm shaft (2) and install shaft on cylinder head.

Lock retaining screws at required torque.

Remove tool 99360612 (1, Figure 54).


Figure 59



117693

Clean the surface of the parts to be joined removing impurities and oil residuals. Apply silicon LOCTITE 275 (1) on the front cover (2) as shown in the picture. The diameter of the sealing string must be $1.5 \pm 0.5/0.2$ mm.

Figure 60




Rotate crankshaft to check conditions below:

- 1) hole identified with two notches (5) is visible through manhole;
- 2) fixture 99360612 (1) through housing (2) of engine rpm sensor inserts in hole (3) on engine flywheel (4).

NOTE To recover the clearances, rotate the crankshaft in a clockwise direction until the opening with the two references is passed and then rotate in the opposite direction to produce the conditions described above.

Figure 61



Position the dial gauge with a magnetic base (1) with the (flat-based) rod positioned on the roller (2) for the rocker arms which controls the exhaust valve for cylinder no. 3 and apply a pre-loading of 6 mm.


NOTE During the measurement the rod for the dial gauge should always be perpendicular to the engine axis and NOT to the surface of the head.

Using tool 99360341 (3, Figure 53), rotate crankshaft clockwise till dial gage arrow reaches minimum value (max cam lift), after which it no longer varies.

Zero set dial gage.

Rotate engine flywheel anticlockwise till dial gage reads camshaft cam lift value = 4.70 ± 0.05 mm.


Figure 62



Camshaft is timed if conditions below are found at cam lift values 4.70 ± 0.05 :

- 1) hole identified with two notches (5) is visible through manhole;
- 2) fixture 99360612 (1) through housing (2) of engine rpm sensor inserts in hole (3) on engine flywheel (4).

Figure 63




In case conditions shown in Figure 62 and shown at paras 1 and 2 are not found, operate as follows:

- 1) release screws (2) securing gear (1) of camshaft to as to make control gear and camshaft independent;
- 2) conveniently operate on engine flywheel so as to obtain conditions indicated at paras 1 and 2, Figure 62, considering that cam lift value must remain unchanged;
- 3) lock screws (2) and repeat control as already described;
- 4) lock screws (2) at required torque.

Timing flywheel

Figure 64



Install gear (5) of high pressure pump and lock nut (4) at required torque.

NOTE When refitting, use the flat washer (PN 17095914) in conjunction with the nut (4) replacing the one supplied with BOSCH pump CP3.

Rotate crankshaft and bring cylinder n.1 piston to compression phase at TDC: Rotate flywheel opposite to regular rotation direction by 1/4 of rev.

Rotate flywheel again in regular rotation direction till hole identified by double notch (3, Figure 64, second box) shows through inspection hole under flywheel cover box.

Insert tool 99360612 (1, Figure 64, second box) in flywheel sensor housing (2, Figure 64, second box).


Fit the flywheel (6) so that the tooth marked with the arrow (↑) is in line with the sensor housing (2, Figure 64, first box).

Insert tool 99360613 (1, Figure 64, first box) through phase sensor housing (2, Figure 64, first box) on tooth machined on tune wheel.

In case tool (1, Figure 64, first box) is difficult to insert, unlock screws (3, Figure 64, first box) and orient tune wheel (6) to properly match the tooth (1, Figure 64, first box).

Lock screws (3, Figure 64, first box).

Figure 65




NOTE Pipes previously removed can no longer be refit. Change them.

Install fuel supply pipeline (1) from high pressure pump to rail. Lock nuts at 35 Nm torque.


! After high-pressure pipe installation, during the following 20 hours of work, frequently check engine oil level (IT MUST NOT INCREASE).

Figure 66



Install centrifugal filter (1) on tune wheel and lock screws (2) at required torque.


Figure 67



Install timing cover (1) and lock retaining screws (2) at required torque.

Intake and exhaust rocker arm clearance adjustment

Figure 68



Adjustment of clearance between rocker arms and intake/exhaust valve control crosspieces must be performed with utmost care. Bring to blast phase cylinder to be adjusted; the valves of this cylinder are closed while the symmetric cylinder valves are balanced. Symmetric cylinders are 1-6; 2-5 and 3-4.

In order to perform these operations correctly, refer to procedure and table below.


- Use a polygonal spanner to release lock nut (1) of rocker arm adjustment screw (2).
- Insert filler gage (3) having same value of operating clearance shown in "Characteristic and data" tables.
- Use special spanner to lock/unlock adjustment screw.
- Check that filler gage (3) slides with a low friction.
- Lock nut (1) retaining the adjustment screw.

IGNITION ORDER 1-4-2-6-3-5

START AND ROTATION CLOCKWISE	BALANCE VALVES OF CYLINDER No.	ADJUST CLEARANCE OF VALVES CYLINDER No.
1 and 6 at TDC	6	1
120°	3	4
120°	5	2
120°	1	6
120°	4	3
120°	2	5

NOTE In order to correctly carry out adjustments above, it is mandatory to perform the sequence indicated in the table, checking exact positioning at each phase by means of pin 99360612.


Figure 69



Install blow-by body (1) with related seal and lock screws (2) at required torque.


Install cover (3) and lock screws (4) at required torque.

Figure 70




Clean the surface of the parts to be joined removing impurities and oil residuals. Apply silicon LOCTITE 406 within the check valve (2) housing (1) and on the Blow-by (3) as shown in the picture.

Figure 71



Fit the head internal electric wire (injectors+pressure sensor) passing it through the opening (5, Figure 69) and securing it using bands as illustrated in the diagram (↓).

Figure 72



Install cylinder head cover (1) and lock screws (2) at required torque following order shown in Figure 73 diagram.

Figure 73






Figure 74



Rotate the engine

Before assembling the suction rose, it is necessary to seal the contact area (I) between basement, flywheel casing and front cover with LOCTITE, following the herein instructions. Clean the surfaces of the parts to be joined removing impurities and oil residuals. Apply silicon LOCTITE 275 (I) as shown in the picture. The diameter of the sealing string must be $1.5 \pm 0.5/0.2$ mm.



Figure 75



114031b

Install suction rose (1).

Figure 76



114029

Fit seal on oil sump (3), fit spacer (2) and install sump on engine block locking screws (1) at required torque.

ENGINE ASSEMBLY COMPLETION


Complete engine assembly fitting or connecting parts below:

- complete fuel filter support and pipelines;
- EDC ecu;
- intake manifold with pre-heating resistor;
- heat exchanger;
- exhaust manifold;
- turbocharger and related water and oil;
- pulley and damper flywheel assy (install fixed guide pulley 5, Figure 4, before assy);
- thermostat assy;
- belt tensioner, water pump, alternator;
- oil level rod;
- start-up motor;
- oil filter;
- electric connections and sensors (See diagram on page 30).

NOTE Fittings of pipelines, cooling water and turbocharger lube oil must be locked at:

- $35 \pm 5\text{Nm}$, water pipeline fittings;
- $55 \pm 5\text{Nm}$, oil pipeline female fitting;
- 20-25 Nm, oil pipeline make fitting.

Figure 77




114291

Use specific equipment (2) to install belt (1) on belt tensioner, in direction shown by arrow.


NOTE Belt tensioner is automatic, therefore no further adjustments are required after installation.

**PART TWO -
ELECTRICAL EQUIPMENT**

COMPONENTS ON THE ENGINE F2C**Figure 78**


- A. Fuel temperature sensor - B. Engine rpm sensor on camshaft - C. Starter motor - D. EDC 7 control unit -
 E. Conditioner compressor - F. Pressure/temperature transmitter - G. Temperature/air pressure sensor -
 H. Alternator - I. Resistance for engine warming - L. Connector on engine block for connection with electro-injectors -
 M. Water temperature sensor - N. Engine speed on flywheel sensor - O. Fuel adjustment valve on high pressure pump


114294

ENGINE CABLE**Figure 79**

119974

Sensor code	FUNCTION
78247	Fuel injector
85157	Fuel pressure sensor on rail
85153	Engine coolant temperature sensor
85156	Air pressure and temperature sensor
42030	Engine oil pressure sensor
47032	Engine oil temperature sensor
78013	Solenoid valve to adjust pressure
47042	Fuel temperature sensor
48035	Driving shaft sensor
48042	Camshaft sensor
ST	Cable routing inside head

EDC 7 UC3I CONTROL UNIT PIN-OUT**Figure 80**

EDC 7 UC3I ELECTRONIC CONTROL UNIT**Figure 8I**


102373

A. Electro-injector connector - B. Chassis connector - C. Sensor connector

EDC CONTROL UNIT PIN-OUT

Electric injector connector "A"

Figure 82




102374

Colour legend

B	black
R	red
U	blue
W	white
P	purple
G	green
N	brown
Y	yellow
O	orange
E	grey
K	pink

Pin	Function
1	Solenoid valve for electronic cylinder 5 injection
2	Solenoid valve for electronic cylinder 6 injection
3	Solenoid valve for electronic cylinder 4 injection
4	Solenoid valve for electronic cylinder 1 injection
5	Solenoid valve for electronic cylinder 3 injection
6	Solenoid valve for electronic cylinder 2 injection
7	-
8	-
9	-
10	-
11	Solenoid valve for electronic cylinder 2 injection
12	Solenoid valve for electronic cylinder 3 injection
13	Solenoid valve for electronic cylinder 1 injection
14	Solenoid valve for electronic cylinder 4 injection
15	Solenoid valve for electronic cylinder 6 injection
16	Solenoid valve for electronic cylinder 5 injection


Sensor connector "C"**Figure 83**

102375

Pin	Function
1÷8	-
9	Engine speed sensor (timing)
10	Engine speed sensor (timing)
11	-
12	Pressure sensor on rail
13	Pressure sensor on rail
14	Pressure sensor on rail
15	Coolant temperature sensor
16	-
17	-
18	Fuel temperature sensor
19	Engine speed sensor (flywheel)
20	-
21	-
22	-
23	Engine speed sensor (flywheel)
24	Engine oil pressure/temperature sensor
25	Air pressure/temperature sensor supply
26	Coolant temperature sensor
27	Engine oil temperature/pressure sensor
28	Engine oil temperature/pressure sensor
29	-
30	-
31	-
32	Engine oil temperature/pressure sensor
33	Air pressure signal from air pressure/temperature sensor
34	Air temperature signal from air pressure/temperature sensor
35	Fuel temperature sensor
36	Air temperature signal from air pressure/temperature sensor

Electroinjectors

Figure 84



114255

It is a N.O. solenoid valve.

They are connected to the EDC ECU on connector A.

The resistance of each injector coil is 0.56 - 0.57 Ohm.

The electroinjector can be considered as consisting of 2 parts:

- ☐ actuator - atomizer including pressure rod, needle and nozzle;
- ☐ control solenoid valve including coil and pilot valve.

The solenoid valve controls atomizer needle lift.

INJECTION START

When coil is energized, lock pin moves upward.

The control volume fuel flows to return duct causing control volume pressure drop.


At the same time, fuel pressure in pressure chamber causes needle uplift and therefore fuel injection in cylinder.

END OF INJECTION

When coil is de-energized, lock pin returns to lock position to look for a force balance such to return to needle close position and stop injection.

This N.T.C. type sensor located on the water outlet sump on the engine head left measures coolant temperature for the various operating logics with a hot or cold engine and identifies injection enrichment requirements for a cold engine or fuel reduction requirements for a hot engine.

Figure 85



104266

Description	Cable colour
To EDC center pin 15 (Sensor connector "C")	K
To EDC center pin 26 (Sensor connector "C")	Y

Fuel temperature sensor


Specifications

Supplier

Max. tightening torque

BOSCH
35 Nm

Figure 86



104267

Description	Cable colour
To pin 18 of EDC control unit (Sensor connector "C")	O/B
To pin 35 of EDC control unit (Sensor connector "C")	W/R

High pressure pump (pressure regulator)

Pump with 3 radial pistons commanded by timing gear, requiring no tuning, with rotor supply pump applied on rear end.

- A. Fuel drain outlet fitting to filter support
- B. Fuel inlet fitting from ECU heat exchanger
- C. Fuel inlet fitting from fuel filter
- D. Fuel outlet fitting from supply pump to filter
- E. Fuel outlet fitting to rail
- 1. High-pressure pump
- 2. Supply pump
- 3. Pressure regulator (NO solenoid valve modulated by ECU with PWM signal).

Pressure regulator

Located at high-pressure pump inlet, on low pressure system, it modulates the amount of fuel for high-pressure pump supply based on commands received from ECU.

It mainly consists of parts below:

- ☐ trapezoidal-section lock pin;
- ☐ valve control pin;
- ☐ pre-load valve;
- ☐ coils.

When no control signal is present, the pressure regulator is normally open, therefore the high pressure pump is in max delivery condition.

The ECU modulates a PWM control signal to extend or reduce section of fuel supply line to high-pressure pump.

The component cannot be replaced as an individual part, therefore it cannot be removed.


The quantity of high-pressure supply fuel is metered by a proportional valve positioned on low-pressure system and it is managed by the ECDC 7 ECU.

The delivery pressure to rail is modulated between 250 and 1400 bars by ECU operating on pressure regulator solenoid valve.

It is a NO solenoid valve.

Its resistance is $\sim 3,2 \Omega$.

It is connected to ECU pins C5 - C7.

Figure 87

000912t


Flywheel pulse transmitter

Specifications

Supplier
Max. tightening torque

BOSCH
8 ± 2 Nm

Figure 88



Description	Cable colour
To EDC center pin 19 (Sensor connector "C")	B
To EDC center pin 23 (Sensor connector "C")	W

Distribution pulse transmitter

Features

Vendor

Torque

Resistance

BOSCH

8 ± 2 Nm


880 ÷ 920 Ω

This induction type sensor located on the camshaft generates signals obtained from the magnetic flow lines that close through the 6 plus 1 phase teeth of a sound wheel mounted on the shaft.

The electronic center uses the signal generated by this sensor as an injection step signal.

This sensor's air gap is NOT ADJUSTABLE.

Figure 89



104269

Description	Cable colour
To EDC center pin 9 (Sensor connector "C")	W
To EDC center pin 10 (Sensor connector "C")	R

Oil temperature/pressure sensor (42030 / 47032)

This component is identical to the air pressure/temperature sensor and replaced single sensors 47032 / 42030.

It is fitted onto the engine oil filter, in a horizontal position.

It measures the engine oil temperature and pressure.


The measured signal is sent to the EDC control unit which controls, in turn, the indicator instrument on the dashboard (low pressure warning lights / gauge).

Pin (EDC)	24/C - 32/C	Power supply
Pin (EDC)	27/C	Pressure
Pin (EDC)	28/C	Temperature

The engine oil temperature is used only by the EDC control unit.

Ref.	Description	Control unit pin
1	Ground	24C
2	Temp. Sign.	28C
3	+5	32C
4	Press. Sign.	27C


Figure 90



50324

Sensor external view


Figure 91



50323

Linking connector

Figure 92



50344

Wiring diagram

Air pressure/temperature sensor (85156).

This component incorporates a temperature sensor and a pressure sensor.

It replaces the temperature sensors (85155) and pressure sensors (85154) available in the preceding systems.

It is fitted onto the intake manifold and measures the maximum supplied air flow rate used to accurately calculate the amount of fuel to be injected at every cycle.


The sensor is powered with 5 V.

The output voltage is proportional to the pressure or temperature measured by the sensor.

Pin (EDC)	25/C - 33/C	Power supply
Pin (EDC)	36/C	Temperature
Pin (EDC)	34/C	Pressure

Ref.	Description	Control unit pin
1	Ground	25C
2	Temp. Sign.	36C
3	+5	33C
4	Press. Sign.	34C


Figure 93



114266

Sensor external view


Figure 94



114273

Linking connector

Figure 95



50344

Wiring diagram

Fuel pressure sensor on rail


Installed on one rail end, it measures actual fuel pressure in order to determine injection pressure.

The injection pressure value is used for pressure check and to determine the injection electric command duration.

It is supplied with 5 volts.

It is connected to ECU on pins 12C - 13C - 14C.

Figure 96



114620

Ref.	Description	Pin ecu
1	ECU pin	12C
2	Ground	13C
3	Supply Pressure	14C

Alternator

Supplier
Technical features

mitsubishi
24V - 90A

Figure 97




Figure 99




Figure 98





Figure 100



Pin	Description
S	+ 30
L	Battery recharge light
B-	Negative
B+	Positive
IG	+ 15

Starting motor

Specifications

Supplier


Type

Electrical system



Nominal output

DENSO
228000564 I
24 Volt
4.5 Kw

Figure 101



CONNECTING DIAGRAM
RELAY



114283

EDC SYSTEM FUNCTIONS

The EDC 7 UC3I electronic center manages the following main functions:

Fuel injection
Accessory functions such as cruise control, speed limiter, PTO and the like
Self-diagnosis
Recovery

It also enables:

Interfacing with other electronic systems (if any) available on the vehicle

Diagnosis

Fuel dosing

Fuel dosing is calculated based on:

- accelerator position
- engine rpm
- quantity of air admitted.

The result can be corrected based on:

- water temperature

or to prevent:

- noise
- fumes
- overloads
- overheating

Pressure can be adjusted in case of:

- engine brake actuation
- external device actuation (e.g. speed reducer, cruise control)
- serious defects involving load reduction or engine stop.

After determining the mass of air introduced by measuring its volume and temperature, the center calculates the corresponding mass of fuel to be injected into the cylinder involved, with account also taken of gas oil temperature.

Delivery correction based on water temperature

When cold, the engine encounters greater operating resistance, mechanical friction is high, oil is still very viscous and operating plays are not optimized yet.

Fuel injected also tends to condense on cold metal surfaces.

Fuel dosing with a cold engine is therefore greater than when hot.

Delivery correction to prevent noise, fumes or overloads

Behaviors that could lead to the defects under review are well known, so the designer has added specific instructions to the center to prevent them.

De-rating

In the event of engine overheating, decreasing delivery proportionally to the temperature reached by the coolant changes injection.

Injection lead electronic control

Injection lead, or the start of fuel delivery expressed in degrees, can differ from one injection to the next, even from one cylinder to another and is calculated similarly to delivery according to engine load, namely, accelerator position, engine rpm and air admitted. Lead is corrected as required:

- during acceleration
- according to water temperature

and to obtain:

- reduced emissions, noise abatement and no overload
- better vehicle acceleration

High injection lead is set at start, based on water temperature.

Delivery start feedback is given by injection electro valve impedance variation.

Engine start

Cylinder I step and recognition signal synchronization (flywheel and drive shaft sensors) takes place at first engine turns. Accelerator pedal signal is ignored at start. Star delivery is set exclusively based on water temperature, via a specific map. The center enables the accelerator pedal, when it detects flywheel acceleration and rpm such as to consider the engine as started and no longer drawn by the starter motor.

Run Up

When the ignition key is inserted, the center transfers data stored at previous engine stop to the main memory (Cf. After run), and diagnoses the system.

After Run

At each engine stop with the ignition key, the center still remains fed by the main relay for a few seconds, to enable the microprocessor to transfer some data from the main volatile memory to a non-volatile, cancelable and rewritable (Eeprom) memory to make them available for the next start (Cf. Run Up).

These data essentially consists of:

- miscellaneous settings, such as engine idling and the like
- settings of some components
- breakdown memory

The process lasts for some seconds, typically from 2 to 7 according to the amount of data to be stored, after which the ECU sends a command to the main relay and makes it disconnect from the battery.

This procedure must never be interrupted, by cutting the engine off from the battery cutout or disconnecting the latter before 10 seconds at least after engine cutout.

In this case, system operation is guaranteed until the fifth improper engine cutout, after which an error is stored in the breakdown memory and the engine operates at lower performance at next start while the EDC warning light stays on.

Repeated procedure interruptions could in fact lead to center damage.

Cut-off

It refers to the supply cut-off function during deceleration.

Cylinder Balancing

Individual cylinder balancing contributes to increasing comfort and operability.

This function enables individual personalized fuel delivery control and delivery start for each cylinder, even differently between each cylinder, to compensate for injector hydraulic tolerances.

The flow (rating feature) differences between the various injectors cannot be evaluated directly by the control unit. This information is provided by the entry of the codes for every single injector, by means of the diagnosis instrument.

NOTE Not present on agricultural versions.

Synchronization search

The center can anyhow recognize the cylinder to inject fuel into even in the absence of a signal from the camshaft sensor.

If this occurs when the engine is already started, combustion sequence is already acquired, so the center continues with the sequence it is already synchronized on; if it occurs with the engine stopped, the center only actuates one electro valve. Injection occurs inside that cylinder within 2 shaft revs at the utmost so the center is only required to synchronize on the firing sequence and start the engine.

PART THREE - TROUBLESHOOTING

PREFACE

A successful troubleshooting is carried out with the competence acquired by years of experience and attending training courses.

When the user complains for bad efficiency or working anomaly, his indications must be kept into proper consideration using them to acquire any useful information to focus the intervention.

Using FPT processing instruments, it is also possible to establish a bi-directional connection with the central unit, by which not only to decoding the failure codes but also input an enquiry relying on memory files, in order to achieve any further necessary information to identify the origin of the anomaly.

Every time there is a breakdown claim and this breakdown is actually detected, it is necessary to proceed inquiring the electronic unit in one of the ways indicated and then proceed with the diagnostic research making trials and tests in order to have a picture of the working conditions and identify the root causes of the anomaly.

In case the electronic device is not providing any indication, it will be necessary to proceed relying on the experience, adopting traditional diagnosis procedures.

NOTE Any kind of operation on the electronic center unit must be executed by qualified personnel, duly authorized by FPT.


Any unauthorized tamper will involve decay of after-sales service in warranty.

DIAGNOSTIC EQUIPMENT

PT-01

PT-01 tester should be used with a Laptop but can be also used singly.

Figure 102



117696

1. Connector with 19-pin diagnosis socket - 2. LED signalling communication between the in-strument - control unit and correct power supply - 3. USB indicator light - 4. Serial port indicator light - 5. Power supply connector (power only to update SW with serial port).

Using PT-01 with portable tester it is possible to execute troubleshooting and test the electronic module of engines.

Main functions:

- ☐ ECU ID reading;
- ☐ Failure memory reading;
- ☐ Flight recorder reading;
- ☐ Parameters reading;
- ☐ Failure memory cleaning;
- ☐ Active diagnosis: actuators activation/testing

Operation without a personal computer


When the connection between the instrument and the diagnosis socket has been establish, the instrument displays the available applications.

Select the application on the numerical keyboard (0 ÷ 9) and confirm with ☒

PT - BOX

PT - BOX is a test tool to be connected to a Personal Computer .

Figure 103



120995

1. Data flow lamps (blinking) - 2. Ignition indicator - 3. USB indicator - 4. Operation indicator -
 5. Serial port indicator - 6. "Error" indicator - 7. CAN line indicator -
 8. Line K indicator for automatic management

With the PT-BOX you can perform:

- ☐ Basic testing: central unit ID reading, failure memory reading, parameter reading, failure memory clearing and "Flight Recorder" memory reading;
- ☐ Active testing: main component testing (actuators, contactors, etc.);
- ☐ "Flight Recorder" reading;
- ☐ ECU acknowledgement of replaced electronic components;
- ☐ 2nd level and PTO programming;
- ☐ Parameter acquisition during operation tests.

FAULT CODES

Failure code	Failure description
Vehicle 1 ((Sensors / Consistency tests)	
I.1.2	ACCELERATOR PEDAL
I.1.9	PLAUSIBILITY +15
I.1.A	PLAUSIBILITY +50
Vehicle 2 (Indicator lamps / Relais / Actuators)	
I.2.3	EDC LAMP
I.2.5	MAIN RELAY DEFECT
I.2.6	BATTERY VOLTAGE
I.2.8	MAIN RELAY - SHORT CIRCUIT TO BATTERY
I.2.9	AIR-CONDITIONER COMPRESSOR RELAY
I.2.B	THERMOSTARTER RELAY I (HEATER)
I.2.E	MANAGEMENT SYSTEM PRE/POST-HEATING (ACTIVE)
2.2.5	INTERRUPTED AFTER-RUN
2.2.8	MAIN RELAY - SHORT CIRCUIT TO GROUND
Engine 1 (Temperature and pressure sensors)	
I.3.1	COOLANT TEMPERATURE SENSOR
I.3.2	COOLANT TEMPERATURE SENSOR (TEST)
I.3.3	AIR TEMPERATURE SENSOR BOOST AIR
I.3.4	BOOST PRESSURE SENSOR
I.3.5	FUEL TEMPERATURE SENSOR
I.3.6	RAIL PRESSURE SENSOR OR SIGNAL ERROR
I.3.7	DBV VALVE MANAGEMENT (BOOST PRESSURE)
I.3.8	OIL PRESSURE SENSOR
I.3.A	OIL TEMPERATURE SENSOR
2.3.2	COOLANT TEMPERATURE SENSOR ABSOLUTE TEST
2.3.6	RAIL PRESSURE SENSOR OFFSET
2.3.8	OIL LOW PRESSURE
2.3.A	OIL TEMPERATURE ABOVE NORMAL
Engine 2 (Speed sensors/actuators)	
I.4.1	CRANKSHAFT SPEED
I.4.2	ENGINE WORKING ONLY WITH CAMSHAFT SENSOR
I.4.3	CAMSHAFT SENSOR
I.4.4	FAULT BETWEEN FLYWHEEL SENSOR AND CAMSHAFT
Damage information	
I.4.D	ENGINE OVERSPEED
I.5.B	HIGH PRESSURE TEST (DEACTIVATES RAIL PRESS.MONITORING)
I.9.D	INDICATES TORQUE LIMITATION DUE TO PERFORMANCE LIMITER
4.9.E	INDICATES THE TORQUE LIMITATION DUE TO ENGINE PROTECTION
6.9.E	INDICATES TORQUE LIMITATION DUE TO FUEL QUANTITY LIMITATION

Failure code	Failure description
Fuel metering	
I.5.1	HIGH PRESSURE SYSTEM
I.5.2	FAULT ON THE FUEL PRESSURE CONTROL OF THE RAIL (POSITIVE DEVIATION)
I.5.3	FAULT ON THE FUEL PRESSURE CONTROL OF THE RAIL (NEGATIVE DEVIATION)
I.5.4	RAIL PRESSURE ERROR: TOO LOW
I.5.5	RAIL PRESSURE ERROR: TOO HIGH
I.5.6	HIGH PRESSURE SYSTEM
I.5.7	ERROR ON THE RAIL PRESSURE (EXCESSIVE DUTY CYCLE)
I.5.8	HIGH PRESSURE SYSTEM
I.5.9	PRESSURE MPROP REGULATOR ERROR
2.5.9	PRESSURE MPROP REGULATOR ERROR (SHORT CIRCUIT TO POSITIVE)
3.5.9	SHORT CIRCUIT TO GROUND OF METERING UNIT OUTPUT
Injectors 1	
I.6.1	INJECTOR CYLINDER 1 / SHORT CIRCUIT
I.6.2	INJECTOR CYLINDER 2 / SHORT CIRCUIT
I.6.3	INJECTOR CYLINDER 3 / SHORT CIRCUIT
I.6.4	INJECTOR CYLINDER 4 / SHORT CIRCUIT
I.6.5	INJECTOR CYLINDER 5 / SHORT CIRCUIT
I.6.6	INJECTOR CYLINDER 6 / SHORT CIRCUIT
I.6.7	INJECTOR CYLINDER 1 / OPEN CIRCUIT
I.6.8	INJECTOR CYLINDER 2 / OPEN CIRCUIT
I.6.9	INJECTOR CYLINDER 3 / OPEN CIRCUIT
I.6.A	INJECTOR CYLINDER 4 / OPEN CIRCUIT
I.6.B	INJECTOR CYLINDER 5 / OPEN CIRCUIT
I.6.C	INJECTOR CYLINDER 6 / OPEN CIRCUIT
I.6.E	THE MINIMUM NUMBER OF INJECTIONS WAS NOT REACHED: STOP THE ENGINE
Injectors 2	
I.7.1	BENCH 1 CC
I.7.3	BENCH 2 CC
I.7.C	BENCH 1 INJECTORS CHECK (INTERNAL ECU)
2.7.C	BENCH 2 INJECTORS CHECK (INTERNAL ECU)
Boosting system and turbine speed	
I.9.E	TORQUE REDUCTION DUE TO SMOKE LIMITATION
Interfaces 1 (CAN-Bus)	
I.B.1	ERROR ON CAN CONTROLLER A
I.B.3	ERROR ON CAN CONTROLLER C
I.B.4	TIMEOUT CAN MESSAGE BC2EDC1
I.B.5	TIMEOUT CAN MESSAGE VM2EDC
I.B.D	TIMEOUT CAN MESSAGE CCVS
2.B.4	TIMEOUT CAN MESSAGE BC2EDC2
Interfaces 2 (CAN line timeout messages)	
I.C.6	ERROR MESSAGE CAN TSC1-PE

Failure code	Failure description
I.C.8	ERROR MESSAGE CAN TSCI -VE
I.C.9	ERROR MESSAGE CAN TF
2.C.6	TIMEOUT OF CAN MESSAGE TSCI -PE PASSIVE
3.C.8	TIMEOUT OF CAN MESSAGE TSCI -VE PASSIVE
ECU 1 (internal checks)	
I.D.1	ECU OVERRUN MONITORING ERROR
I.D.2	ECU OVERRUN MONITORING ERROR
I.D.3	ECU OVERRUN MONITORING ERROR
I.D.4	ECU OVERRUN MONITORING ERROR
I.D.5	ECU OVERRUN MONITORING ERROR
I.D.6	ECU INTERNAL ERROR (TPU)
I.D.7	INTERNAL ECU ERROR (VARIANT AREA)
I.D.8	ECU OVERRUN MONITORING ERROR
I.D.9	ECU OVERRUN MONITORING ERROR
2.D.3	ECU OVERRUN MONITORING ERROR
3.D.3	ERRORE INTERNO CENTRALINA
ECU 2 (Power supply / Immobilizer / Runaway / Sensor power supply)	
I.E.1	ECU: SHORT CIRCUIT OR OPEN CIRCUIT
I.E.3	ERROR FOR ECU INTERNAL MONITORING
I.E.4	ERROR FOR ECU INTERNAL MONITORING
I.E.5	SENSORS POWER SUPPLY FAULT (12V)
I.E.6	SENSOR POWER SUPPLY 1
I.E.7	SENSOR POWER SUPPLY 2
I.E.8	SENSOR POWER SUPPLY 3
I.E.9	ECU OVERRUN MONITORING ERROR
I.E.A	ECU OVERRUN MONITORING ERROR
I.E.B	ATMOSPHERIC PRESSURE SENSOR
2.E.1	SHORT CIRCUIT TO BATT OR GROUND, NO LOAD, EXCESS.TEMP. FOR LOW SIDE POWER STAGE

**PART FOUR -
MAINTENANCE PLANNING**

MAINTENANCE PLANNING

Recovery

To ensure optimised working conditions, in the following pages we are providing instructions for the overhaul control interventions, checks and setting operations that must be performed on the engine at due planned dates.

The frequency of the maintenance operations is just an indication since the use of the engine is the main characteristic to determine and evaluate replacements and checks.

It is not only allowed but recommended that the staff in charge of the maintenance should also carry out the necessary maintenance and controlling operations even if not being included in the ones listed here below but that may be suggested by common sense and by the specific conditions in which the engine is run.

Planning of controls and periodical intervention

Type of operation	Every 150 hours	Every 300 hours	Every 600 hours	Every 1200 hours
Engine				
Engine oil topping up	•			
Change engine oil			•	
Change engine oil filters			•	
Change of blow-by filter			•	
Replacing fuel filter		•		
Adjustment of valve clearance				•
Change miscellaneous drive belts				•
Chassis and mechanical assemblies				
Change fuel pre-filter (if available)		•		

NOTE The maintenance operations are valid only if the setter fully complies with all the installation prescriptions provided by Iveco Motors.

NOTE The engine lubrication intervals apply with the use of Diesel fuel with sulphur content of less than 0.5%.
If using diesel with a percentage of sulphur above 0.5%, the oil-change frequency has to be halved.

Use engine oil: **ACEA E3 - 96**

NOTE Diesel fuel for low temperatures. Standard EN590 defines different classes of Diesel fuels, identifying the characteristics of those most suitable for use in low ambient temperatures.
Compliance with the regulations regarding the distribution of fuels suitable for the climatic and geographic conditions of the various countries is entirely up to the oil companies.



- ☐ The engine oil and filters must be changed every 12 months in case of very low annual use or less than 600 hours.
- ☐ Premature clogging of the air cleaner is generally due to the operating conditions. The filter should therefore be renewed whenever clogging is signalled by the sensor regardless of the prescribed time interval, which should in any case be respected in the absence of any specific indications.



The time intervals given in this plan are merely approximate as they refer to using the engines in an industrial environment with average use in relation to displacement.

OFF-PLANE OPERATIONS

Every year – Before winter

and possibly when a maintenance operation is carried out

Check the antifreeze percentage in the engine cooling water

Every two year

and possibly when a maintenance operation is carried out

Change engine coolant

NOTE Early air filter clogging is usually due to environmental conditions. For this reason, the filter should be changed if clogging is signalled by the related sensor, regardless of the prescriptions that shall be observed if no specific indications have been provided.

MAINTENANCE PROCEDURES


Checks and controls

Engine oil level check

The check must be executed when the engine is disconnected and possibly cool.

The check can be made using the specially provided flexible rod (1).

Figure 104 (Demonstration)




145841

Draw off the rod from its slot and check that the level is within the etched tags of minimum and maximum level.

Whether it should be difficult to make the evaluation, proceed cleaning the rod using a clean cloth with no rag grinding and put it back in its slot. Draw it off again and check the level.

In case the level results being close to the tag showing minimum level, provide filling lubrication of the engine's components.

Figure 105 (Demonstration)



145842

Top up via the tappet cover cap (2). When filling, remove the dipstick (1) to facilitate the flow of oil.



The engine oil is highly polluting and harmful.



In case of contact with the skin, rinse well with water and detergent.

Adequately protect the skin and the eyes, operate in full compliance with safety regulations.

Disposal must be carried out properly, and in full compliance with the law and regulations in force.

Lubricating system check

The check must be executed both when the engine disconnected and when it is running.

Verify the presence of any oil leakage or blow-by from the head, from the engine pan or from the heat exchanger.



The engine oil is highly polluting and harmful.




In case of contact with the skin, rinse well with water and detergent.

Adequately protect the skin and the eyes, operate in full compliance with safety regulations.

Disposal must be carried out properly, and in full compliance with the law and regulations in force.

Engine oil change

Figure 106



We recommend to carry out the oil drainage when the motor is hot.



Warning: We recommend to wear proper protections because of high motor service temperature.

The motor oil reaches very high temperature: you must always wear protection gloves.

- ☐ Place a proper container for the oil collecting under the pan connected with the drain plug (3).
- ☐ Unscrew the plug (3) and then take out the control dipstick (1) and the inserting plug (2) to ease the downflow of the lubrication oil.



The oil motor is very pollutant and harmful.

In case of contact with the skin, wash with much water and detergent.



Protect properly skin and eyes: operate according to safety rules.

Dispose of the residual properly following the rules.


- ☐ After draining completely, screw on the plug (3) under the sump and tighten it to the prescribed torque.
- ☐ Add the specified quantity of recommended engine oil through the filler (2) of the tappets cover.

NOTE Use only the recommended oil or oil having the requested features for the correct motor functioning. In case of topping up, don't mix oils having different features. If you don't comply with these rules, the service warranty is no more valid.

- ☐ Check the level through the dipstick until when the filling is next to the maximum level notch indicated on the dipstick.

Engine oil filter change

Figure 107



Drain the oil as described in the section "Changing the engine oil".

NOTE Warning: the oil filter contains inside a quantity of oil of about 1 kg.



Place properly a container for the liquid.

Warning: avoid the contact of skin with the motor oil: in case of contact wash the skin with running water.

The motor oil is very pollutant: it must be disposed of according to the rules.

NOTE Before refitting the new cartridge, wet seal using engine oil.

Screw the oil filter (1) by hand until it touches the support, then tighten $\frac{3}{4}$ of a turn to the required torque.


Refit the plug under the sump, tightening it to the required torque.

Add the required amount of recommended engine oil through the filler.

Complete the operation as described in the section "Changing the engine oil".


Changing the Blow-by filter

Figure 108



Unlock screws (2) and remove cover (1). Remove the centrifugal filter (3) underneath and replace it.

Figure 109




Install blow-by body (1) with related seal and lock screws (2) at required torque.

Install cover (3) and lock screws (4) at required torque.

Fuel filter change

Figure 110



During this operation don't smoke and don't use free flames.

Avoid to breathe the vapors coming from filter.



After filters replacement the supply equipment deaeration must be carried out.

Unscrew the fuel filter cartridge (2).

Before fitting the new cartridge, wet seal with fuel oil or engine oil.

Lock the new one by hand and carefully check that rubber seal and contact surface are clean and in perfect conditions.

Lock cartridge by hand till contact with support and then lock it for $\frac{3}{4}$ of a rev. at prescribed tightening torque.




When replacing the filter cartridge (2) do **NOT** fill it.

This operation is banned to avoid impurities entering into the circuit, which would damage the injector/pump system components.

Bleed air from the fuel as described below.

Fuel bleeding

Loosen the bleed screw (1) connecting the drainage by a transparent flexible hose to a suitable container.

Figure I 11

145887

With the hand pump (2) of the fuel pre-filter (1) pump until fuel completely free of air bubbles flows from the bleed screw.


After the operation, tighten the bleed screw.

Start the engine and allow it to run at minimum for a few minutes to expel any remaining air.

Valve lash check a adjustment

For correct operation, follow instructions contained in related chapter in section 3 – Industrial Application.

Check of water pump/alternator control belt condition

Figure I 12

145888

Visually check that belt (4) is not worn out or broken; change it as described below, if required.

NOTE To be able to work on the engine belt you first need to remove the protective casing (if applicable) by unscrewing the screws.

Use appropriate equipment (5) on the belt tensioner (6) in the direction shown by the arrow and extract the belt (4) from the pulleys of the alternator (1), of the coolant pump (2) and from the idler pulleys (3).

- ☐ Replace the worn belt with a new one.
- ☐ Place the belt on the pulleys and the guide rollers.
- ☐ Place the automatic tightener in order to key the belt in the functioning position.
- ☐ Further adjustments are not required.

Replacing coolant

Only proceed with the engine stopped and at a low temperature, so as to avoid the risk of burning.

- ☐ Provide suitable containers to ensure that no coolant is dispersed into the environment.
- ☐ Loosen the seal elements, remove the sleeves connecting the engine circuit to the heat exchanger and wait until it has emptied completely. When empty, repair the circuit making sure that the sleeves are perfectly sealed.
- ☐ Fill up the circuit.
- ☐ Refill the engine and the heat exchanger until complete top up.
- ☐ With the filler cap open, start the engine and keep it idling for nearly one minute. This phase facilitates the cooling liquid air bleed.
- ☐ Stop the engine and top up again.







SECTION 4**Overhaul and technical specifications**








	Page
GENERAL CHARACTERISTICS	3
ASSEMBLY CLEARANCE DATA	5
ENGINE OVERHAUL	11
ENGINE REMOVAL AT THE BENCH	11
REPAIR OPERATIONS	12
CYLINDER BLOCK	12
<input type="checkbox"/> Checks and measurements	12
CYLINDER LINERS	13
<input type="checkbox"/> Replacing cylinder liners	15
CRANKSHAFT	16
<input type="checkbox"/> Measuring main journals and crank pins	17
PRELIMINARY MEASUREMENT OF MAIN AND BIG END BEARING SHELL SELECTION DATA	18
<input type="checkbox"/> Selecting the main and big end bearing shells	19
<input type="checkbox"/> Replacing the timing control gear and the oil pump	25
<input type="checkbox"/> Checking main journal installation clearance	25
<input type="checkbox"/> Checking crankshaft end float	26
PISTON-CONNECTING ROD ASSEMBLY	27
<input type="checkbox"/> Removal	27
<input type="checkbox"/> Conditions for correct gudgeon pin-piston coupling	28
<input type="checkbox"/> Piston rings	29

	Page
CONNECTING ROD	30
<input type="checkbox"/> Mounting the connecting rod - piston assembly	32
<input type="checkbox"/> Mounting the piston rings	32
<input type="checkbox"/> Fitting the connecting rod-piston assembly into the piston liners	33
<input type="checkbox"/> Piston protrusion check	33
<input type="checkbox"/> Checking assembly clearance of big end pins ..	34
CYLINDER HEAD	34
<input type="checkbox"/> Dismounting the valves	34
<input type="checkbox"/> Checking the planarity of the head on the cylinder block	34
VALVE	35
<input type="checkbox"/> Removing deposits and checking the valves ...	35
VALVE GUIDES	35
<input type="checkbox"/> Replacing of valve guides	36
<input type="checkbox"/> Replacing - Reaming the valve seats	36
REPLACING INJECTOR HOLDER CASES	36













	Page
TIMING GEAR	39
<input type="checkbox"/> Camshaft drive	39
<input type="checkbox"/> Intermediate gear pin	39
<input type="checkbox"/> Idler gear	39
<input type="checkbox"/> Twin idler gear	39
<input type="checkbox"/> Replacing the bushings	39
<input type="checkbox"/> Camshaft	40
<input type="checkbox"/> Checking cam lift and pin alignment	40
<input type="checkbox"/> Bushes	41
<input type="checkbox"/> Use beater 99360505 to change bushings	42
VALVE SPRINGS	42
<input type="checkbox"/> Fitting the valves and oil seal ring	42
ROCKER SHAFT	43
<input type="checkbox"/> Shaft	43
<input type="checkbox"/> Rocker	43
TIGHTENING TORQUES	44













GENERAL CHARACTERISTICS

	Type	F2CE9687	
	Cycle	4-stroke Diesel engine	
	Fuel feed	Turbocharged	
	Injection	Direct	
	No. of cylinders	6 in line	
	Bore	mm	117
	Stroke	mm	135
	Total displacement	cm ³	8710














	Type	F2CE9687	
	<p>VALVE TIMING</p> <p>opens before T.D.C. A</p> <p>closes after B.D.C. B</p> <p>opens before B.D.C. D</p> <p>closes after T.D.C. C</p>		<p>17°</p> <p>31°</p> <p>48°</p> <p>9°</p>
	<p>For timing check</p> <p>Running</p> <p>× { mm</p> <p>mm</p> <p>× { mm</p> <p>mm</p>		<p>-</p> <p>-</p> <p>0.35 to 0.45</p> <p>0.55 to 0.65</p>
	FEED	Bosch Common Rail with CRIN2 injectors and high pressure pump CP3.3	
	Nozzle type	DLA 137	
	Injection order	1 - 4 - 2 - 6 - 3 - 5	
	Injection pressure	bar	1800
	Injector calibration	bar	

ASSEMBLY CLEARANCE DATA























	Type	F2CE9687	
CYLINDER BLOCK AND CRANKMECHANISM COMPONENTS		mm	
	Bores for cylinder liners: upper Ø1 lower	130.500 to 130.525 129.510 to 129.535	
	Cylinder liners: external diameter: upper Ø2 lower length L	130.461 to 130.486 129.475 to 129.500 226,15 226.15	
	Cylinder liners - crankcase bores upper lower	0.014 to 0.064 0.010 to 0.060	
	External diameter Ø2	-	
	Cylinder sleeve inside diameter Ø3A* inside diameter Ø3B* Protrusion X	117.000 to 117.012 117.010 to 117.022 0.035 to 0.065	
	Pistons: measuring dimension X external diameter Ø1A external diameter Ø1B pin bore Ø2	15 116.894 to 116.906 116.904 to 116.916 52.010 to 52.016	
	Piston - cylinder sleeve A* B*	0.094 to 0.118 0.094 to 0.118	
	Piston diameter Ø1	-	
	Pistons protrusion X	0.873 to 1.117	
	Gudgeon pin Ø3	51.994 to 52.000	
	Gudgeon pin - pin housing	0.010 to 0.022	












	Type	F2CE9687	
		mm	
	Piston ring grooves	X1	3,120 ÷ 3,140
		X2	3.120 to 3.140
		X3	2.550 to 2.570
		X3	4.020 to 4.040
	Piston rings: trapezoidal seal	S1	3.000
	lune seal	S2	2.470 to 2.500
	milled scraper ring with slits and internal spring	S3	3.970 to 3.990
	Piston rings - grooves	1	-
		2	0.050 to 0.100
		3	0.030 to 0.070
	Piston rings		-
	Piston ring end gap in cylinder liners	X1	0.3 to 0.4
		X2	0.60 to 0.75
		X3	0.35 to 0.65
	Small end bush housing	Ø1	55.700 to 55.730
	Big end bearing housing	Ø2	85.987 to 86.013
	Selection classes	1	85.987 to 85.996
		2	85.997 to 86.005
		3	86.006 to 86.013
	Small end bush diameter outside	Ø4	55.780 to 55.820
	inside	Ø3	52.015 to 52.030
	Big end bearing shell	S	
	Red		1.994 to 2.002
	Green		2.002 to 2.010
	Yellow ●		2.010 to 2.018
	Small end bush - housing		0.05 to 0.08
	Piston pin - bush		0.015 to 0.036
	Big end bearing		0.127 - 0.254 - 0.508
	Connecting rod weight	A	g
	Class	A	3450 to 3470
		B	3471 to 3490
		C	3491 to 3510








- Fitted in production only and not supplied as spares

	Type	F2CE9687	
		mm	
	Measuring dimension X	X	125
	Max. connecting rod axis misalignment tolerance	=	0.08
  	Main journals	Ø1	92.970 to 93.000
	- nominal		92.970 to 92.980
	- class	1	92.980 to 92.990
	- class	2	92.990 to 93.000
	- class	3	
	Crankpins	Ø2	81.915 to 81.945
	- nominal		81.915 to 81.925
	- class	1	81.925 to 81.935
	- class	2	81.935 to 81.945
	- class	3	
	Main bearing shells	S1	2.968 to 2.978
	Red		2.978 to 2.988
	Green		2.988 to 2.998
	Yellow*		
	Big end bearing shells	S2	1.994 to 2.002
	Red		2.002 to 2.010
	Green		2.010 to 2.018
	Yellow*		
	Main bearing housings	Ø3	99.000 to 99.030
	- nominal		99.000 to 99.009
	- class	1	99.010 to 99.019
	- class	2	99.020 to 99.030
	- class	3	
	Bearing shells - main journals		0.050 to 0.090
	Bearing shells - big ends		0.040 to 0.080
	Main bearing shells		0.127 - 2.254 - 0.508
	Big end bearing shells		0.127 - 2.254 - 0.508
	Main journal, thrust bearing	X1	39.96 to 40.04
	Main bearing housing, thrust bearing	X2	38.94 to 38.99
	Thrust washer halves	X3	3.38 to 3.43
	Crankshaft end float		0.10 to 0.30
	Alignment	=	1 - 2
	Ovalization	○	1 - 2
	Taper	>	1 - 2

* Fitted in production only and not supplied as spares

	Type	F2CE9687	
CYLINDER HEAD - VALVE TRAIN		mm	
	Valve guide housings in cylinder head	Ø 1	12.9800 to 12.997
	Valve guide	 Ø 2 Ø 3	8.023 to 8.038 13.012 to 13.025
	Valve guides - housings in the cylinder heads		0.015 to 0.045
	Valve guide		0.2 - 0.4
	Valves:	 Ø 4 α  Ø 4 α	7.970 to 7.985 60° 30' ± 7' 30" 7.970 to 7.985 45° ⁺¹⁵ ₋₀
	Valve stem and its guide		0.040 to 0.070
	Valve seat in head	 Ø 1  Ø 1	41.985 to 42.020 40.985 to 41.020
	Outside diameter of valve seat; angle of valve seat in cylinder head:	 Ø 2 α  Ø 2 α	⁰ _{-0.5} 42.060 to 42.075 60° - 30' ⁰ _{-0.5} 41.060 to 41.075 45° - 30'
	Recessing of valve	 X  X	0.5 to 0.8 1.6 to 1.9
	Between valve seat and head	 	0.040 to 0.090

	Type	F2CE9687	
		mm	
	Valve spring height:	A	B
	free height	70.77	71.34
	under a load of:	51	
	N 460 ± 23 H1A } N 460 ± 22 H1B } N 740 ± 33 H2A } N 731,4 ± 42 H2B }	39	
	Injector protrusion	1.2 to 1.5	
	Camshaft bushing housing in the cylinder head: I ⇒ 7	69.000 to 69.030	
	Camshaft bearing journals: I ⇒ 7	64.924 to 64.080	
	Outer diameter of camshaft bushings:	69.090 to 69.130	
	Inner diameter of camshaft bushings:	65.080 to 65.116	
	Bushings and housings in the cylinder head	0.060 to 0.130	
	Bushings and bearing journals	0.100 to 0.192	
	Cam lift:	7.4034	8.2108
	Rocker shaft	31.964 to 31.980	


	Type	F2CE9687
		mm
	Bushing housing in rocker arms	32.025 to 32.041
	 	32.025 to 32.041
	Between bushings and housings	0.045 to 0.077
	 	0.045 to 0.077
TURBOCHARGER		
Type		HX40
End float		0.025 to 0.127
Radial play		0.330 to 0.508

ENGINE OVERHAUL ENGINE REMOVAL AT THE BENCH

The following instructions are prescribed on the understanding that the engine has previously been placed on the rotating bench and that removal of all specific components of the equipment have been already removed as well. (See Section 3 of the manual herein).

The section illustrates therefore all the most important engine overhaul procedures.


Figure 1



115881

Rotate the block (1) to the vertical position.

Figure 2



115882


Untighten screws (2) fixing the connecting rod cap (3) and remove it. Remove the connecting rod-piston (1) assembly from the upper side.

Repeat these operations for the other pistons.



Keep the big end bearing shells in their respective housings and/or note down their assembly position since, if reusing them, they will need to be fitted in the position found upon removal.

Figure 3




114615

Use adequate hexagonal spanner, unlock screws (1 and 3) and remove stiffening plate (2) as well as main journals (4).

NOTE Note down the assembly position of the top and bottom main bearing shells since, if reusing them, they will need to be fitted in the position found upon removal.


Figure 4



114035

Using tool 99360500 (1), remove the crankshaft (2).

Figure 5



47571

Remove the main bearing shells (1), unscrew the screws and take out the oil nozzles (2). Remove the cylinder liners as described under the relevant subheading on page 15.




After disassembling the engine, thoroughly clean disassembled parts and check their integrity.

Instructions for main checks and measures are given in the following pages, in order to determine whether the parts can be re-used.

REPAIR OPERATIONS CYLINDER BLOCK

Checks and measurements

Figure 6 (Demonstration)




34994

Internal diameter of the cylinder liners is checked for ovalization, taper and wear, using a bore dial (1) centesimal gauge 99395687 (2) previously reset to ring gauge (3), diameter 117 mm.

NOTE If dia.117 mm ring gage is not available, use a micrometer.

Figure 7




114035

- 1 = 1st measuring
- 2 = 2nd measuring
- 3 = 3rd measuring

Carry out measurements on each cylinder liner at three different levels and on two (A-B) surfaces, to one another perpendicular, as shown in Figure.

Figure 8




225036

- A = Selection class $\varnothing 117 - 117.012$ mm
- B = Selection class $\varnothing 117.010 - 117.022$ mm
- X = Selection class marking area

In case of maximum wear >0.150 mm or maximum ovalization >0.100 mm compared to the values indicated in the figure, the liners must be replaced as they cannot be ground, lapped or trued.

NOTE Cylinder liners are equipped with spare parts with "A" selection class.

Figure 9



114037


- A = $\varnothing 130.500$ to 130.525 mm
- B = $\varnothing 129.510$ to 129.535 mm
- C = $\varnothing 130.461$ to 130.486 mm
- D = $\varnothing 129.475$ to 129.500 mm

The figure shows the outer diameters of the cylinder liners and the relative seat inner diameters.

The cylinder liners can be extracted and installed several times in different seats, if necessary.

CYLINDER LINERS


Figure 10



114038

CYLINDER BLOCK ASSEMBLY WITH CHROME-PLATED CYLINDER LINERS

Figure 11




145836

CYLINDER LINERS MAIN DATA

Selection class

{ A mm 117.000 to 117.012
 B mm 117.010 to 117.022


Figure 12



DETAIL A

145837

Figure 13




DETAIL B

145838

Replacing cylinder liners

Removal

Figure 14




Place details 99360706 (1 and 2) and plate 99360724 (4) as shown in the figure, by making sure that the plate (4) is properly placed on the cylinder liners.

Tighten the screw nut (1) and remove the cylinder liner (3) from the block.

Fitting and checking protrusion

Figure 15




Always replace water sealing rings (3, 4 and 5).

Install the adjustment ring (1) on the cylinder liner (2); lubricate lower part of liner and install it in the cylinder unit using the proper tool.

NOTE The adjustment ring (1) is supplied as spare parts in the following thicknesses: 0.08 mm - 0.10 mm - 0.12 mm.

Figure 16



Check cylinder barrel protrusion with tool 99360334 (1-2-3-4) and tighten screw (1) to 170 Nm.

With dial gauge 99395603 (5) placed on base 99370415 (6) measure the cylinder barrel protrusion compared to the cylinder head supporting plane, it must be 0,035 to 0,065 mm (Figure 17); otherwise replace the adjusting ring (1, Figure 15) fitted with spare parts having different thickness.

Figure 17





Figure 18 (Demonstration)




When the installation is completed, block the cylinder liners (1) to the block (2) with studs 99360703 (3).

Measuring main journals and crank pins


Before grinding the crank pins using a micrometer (1), measure the main journals and the crank pins (2) and decide, on the basis of the undersizing of the bearings, the final diameter to which the pins are to be ground.

Figure 22



NOTE It is advisable to enter the values found in a table (Figure 24).

Figure 23



MEASURING CRANK PINS

During grinding, pay attention to journal and crank pins values specified in figures 19 and 20.


NOTE All journals and crank pins must also be ground to the same undersizing class, in order to avoid any alteration to shaft balance.

Figure 24

Fill in this table with the measurements of the main journals and the crank pins.

MAIN JOURNALS

Ø MIN.
Ø MAX.



CRANK PINS

114045

PRELIMINARY MEASUREMENT OF MAIN AND BIG END BEARING SHELL SELECTION DATA

For each of the journals of the crankshaft, it is necessary to carry out the following operations:

MAIN JOURNALS:

- ☐ Determine the class of diameter of the seat in the crankcase.
- ☐ Determine the class of diameter of the main journal.
- ☐ Select the class of the bearing shells to mount.

CRANKPINS:


- ☐ Determine the class of diameter of the seat in the connecting rod.
- ☐ Determine the class of diameter of the crankpin.
- ☐ Select the class of the bearing shells to mount.

DEFINING THE CLASS OF DIAMETER OF THE SEATS FOR BEARING SHELLS ON THE CRANKCASE

On the front of the crankcase, two sets of numbers are marked in the position shown (Figure 25 at top).

- ☐ The first set of digits (four) is the coupling number of the crankcase with its base (Figure 25 at bottom).
- ☐ The following seven digits, taken singly, are the class of diameter of each of the seats referred to (Figure 25 at bottom).
- ☐ Each of these digits may be **1**, **2** or **3**.

Figure 25



114046

Selecting the main and big end bearing shells

NOTE To obtain the required assembly clearances, the main and big end bearing shells need to be selected as described hereunder.



This operation makes it possible to identify the most suitable bearing shells for each of the journals (the bearing shells, if necessary, can have different classes from one journal to another).

Depending on the thickness, the bearing shells are selected in classes of tolerance marked by a coloured sign (red-green – red/black – green/black).


The following tables give the specifications of the main and big end bearing shells available as spares in the standard sizes (STD) and in the permissible oversizes (+0.127, +0.254, +0.508).

Figure 26

	STD	+0.127
red	1.994 to 2.002	
red/black		2.057 to 2.065
green	2.002 to 2.010	
green/black		2.065 to 2.073
yellow*	2.010 to 2.018	
yellow/black*		2.073 to 2.081



	STD	+0.127
red	2.968 to 2.978	
red/black		3.031 to 3.041
green	2.978 to 2.988	
green/black		3.041 to 3.051
yellow*	2.988 to 2.998	
yellow/black*		3.051 to 3.061



* Fitted in production only and not supplied as spares


DEFINING THE CLASS OF DIAMETER OF THE MAIN JOURNALS AND CRANKPINS (Journals with nominal diameter)

Main journals and crankpins: determining the class of diameter of the journals.

Three sets of numbers are marked on the crankshaft in the position shown by the arrow (Figure 27 at top):

- ☐ The first number, of five digits, is the part number of the shaft.
- ☐ Under this number, on the left, a set of six digits refers to the crankpins and is preceded by a single digit showing the status of the journals (1 = STD, 2 = -0.127), the other six digits, taken singly, give the class of diameter of each of the crankpins they refer to (Figure 27 at top).
- ☐ The set of seven digits, on the right, refers to the main journals and is preceded by a single digit: the single digit shows the status of the journals (1 = STD, 2 = -0.127), the other seven digits, taken singly, give the class of diameter of each of the main journals they refer to (Figure 27 at bottom).

Figure 27




Selection of main half-bearings (nominal diameter pins)

After detecting, for each journal, the necessary data on block and crankshaft, select the type of half-bearings to be used, in compliance with the following table:

Figure 28


STD.



1

2

3



1

green

green

yellow

green

yellow

yellow

2

red

green

green

green

green

yellow

3

red


red

green

red

green

green



Selection of main half-bearings (rectified pins)

If the journals have been rectified, the procedure described cannot be applied.

In this case, make sure that the new diameter of the journals is as specified on the table and install the only half-bearing type required for this undersizing.


Figure 29


red/black =
mm 3.031 to 3.041

green/black =
mm 3.041 to 3.051

green/black =
mm 3.0513 to 3.061

-0.127





92.843
92.853

1

green/black

green/black

92.853
92.863

2

red/black

green/black

92.863
92.872

3


red/black

red/black

2

green/black

yellow/black



green/black

green/black

red/black

green/black

3

yellow/black

yellow/black

green/black

yellow/black

green/black

green/black

SELECTING THE BIG END BEARING SHELLS
(JOURNALS WITH NOMINAL DIAMETER)

There are 4 references on the connecting rod casing in the positions illustrated:

- 1. Coloured mark for identifying the weight
- 2. Coloured mark for identifying the diameter grade
- 3. Positioning stud visible from the front of the engine
- 4. Progressive number for identifying the connecting rod

NOTE The identification colours of the marks are given in the table on page 31.

The number, indicating the class of diameter of the bearing shell seat may be **1, 2** or **3**.

Determine the type of big end bearing to fit on each journal by following the indications in the table (Figure 31).

Figure 30







Figure 31

STD.




Class	1 yellow	2 green	3 blue
1	green	green	yellow
	green	yellow	yellow
2	red		green
	green		yellow
3	red	red	green
	red	green	green

Replacing the timing control gear and the oil pump

Check that the teeth of the gears are not damaged or worn, otherwise remove them using the appropriate extractor.

Figure 33




NOTE Before fitting the gear, spread Loctite type 603 on approx. 5 mm wide band on crankshaft, at 30 mm from contact surface.

After fitting the gear (1) on the crankshaft (2), heat it for ~15 minutes in an oven at temperature not higher than 180°C.

Let them cool down after the installation.

Checking main journal installation clearance


Figure 34



Fit the oil jets (2) aligning the dowel with the opening (3) in the crankcase.


Position the half-bearings (1) and the thrust washers on the main journal supports as illustrated in Figure 19.

Figure 35



Using the hoist and hook 99360500 (1) mount the driving shaft (2).


Figure 36



Place bearing halves (1) on main journals (2).


Check the installation clearance between the main journals and the relative bearings as follows.

Figure 37



- ☐ Clean accurately the parts and remove any trace of oil;
- ☐ Fit caps (1), including the half bearings (2) on the relevant supports.


Figure 38



- ☐ Position the main journal caps (4) and fit the strengthening plate (2) following the procedure described:
- ☐ Tighten the inner bolts and then the outer bolts by hand starting from main journal "7" and continuing until main journal "1".
- ☐ Tightening the bolts using torque wrench always starting from main journal "7" and continuing until main journal "1":
1st stage: 140 Nm
2nd stage 60°+60°

Checking crankshaft end float

Figure 39




End float is checked by placing a magnetic dial gauge (1) on the crankshaft (2), as shown in the figure.

If the value obtained is higher than specified, replace the rear thrust half-bearings and repeat this check.

PISTON-CONNECTING ROD ASSEMBLY

Figure 40



47580

PISTON CONNECTING ROD ASSEMBLY

1. Connecting rod body - 2. Half bearings - 3. Connecting rod cap - 4. Cap fastening screws - 5. Split ring - 6. Scraper ring with spiral spring - 7. Bevel cut sealing ring - 8. Trapezoidal sealing ring - 9. Piston pin - 10. Piston


Make sure the piston does not show any trace of seizing, scoring, cracking; replace as necessary.

Pistons are equipped with three elastic rings: a sealing ring, a trapezoidal ring and a scraper ring.

Pistons are grouped into classes A and B for diameter.

Removal


Figure 41



126311

Removal of the piston split rings (2) using the pliers 99360184 (1).


Figure 42



126312

Remove the piston pin split rings (2) using the round tipped pliers (1).

Figure 43




49026

Remove the piston pin (1).

If removal is difficult use the appropriate beater.

Figure 44




32618

Measuring the gudgeon pin diameter (1) with a micrometer (2).

Conditions for correct gudgeon pin-piston coupling


Figure 45



49026

Lubricate the pin (1) and the relevant housing on the piston hubs with engine oil; piston must be inserted with a slight finger pressure and it should not come out by gravity.

Figure 46




MAIN DATA OF PISTON, SNAP RINGS AND PIN

$X = 0,6 \pm 0,15$

- The dimension is measured on a \varnothing of 113 mm


Piston rings

Figure 47




Check the thickness of the piston ring (2) using a micrometer (1).

Figure 48




Check the clearance between the sealing rings (2) and the relative piston housings (1) using a thickness gauge (3).

Figure 49



The sealing ring (2) of the 1° cavity is trapezoidal. Clearance "X" between the sealing ring and its housing is measured by placing the piston (1) with its ring in the cylinder barrel (3), so that the sealing ring is half-projected out of the cylinder barrel.

Figure 50



Check the opening between the ends of the sealing rings (1), using a thickness gauge (2), entered in the cylinder barrel (3).


If the distance between ends is lower or higher than the value required, replace split rings.

CONNECTING ROD



When fitting the connecting rods, check that all of them are of same weight class and from the same supplier. The connecting rod/cap is of "torn" type; before assembly verify that the connecting rod is not damaged. Each connecting rod can be assembled with the relative cap only. If the cap is assembled on the reverse side, the connecting rod must be rejected.

Figure 51




114054

MAIN DATA - BUSH, CONNECTING ROD, PIN AND HALF-BEARINGS

* Values to be obtained after installing the bush

- 1 Between the connecting rod bush and the connecting rod profile there must be a distance > 0.4 mm.
- 2 On the external breaking line, gap area allowed must be $< 5 \text{ mm}^2$.
- 3 No cracks are allowed in the threaded area.

Figure 52



115884


1. Coloured mark for identifying weight - 2. Coloured mark for identifying diameter grade - 3. Positioning stud visible from the front of the engine - 4. Progressive number for identifying connecting rod

WEIGHT		DIAMETER	
GRADE A Yellow	3450 g - 3470 g	Ø 85.987-85.996	Yellow
		Ø 85.997-86.005	Green
		Ø 86.006-86.013	Blue
GRADE B Green	3471 g - 3490 g	Ø 85.987-85.996	Yellow
		Ø 85.997-86.005	Green
		Ø 86.006-86.013	Blue
GRADE C Blue	3491 g - 3510 g	Ø 85.987-85.996	Yellow
		Ø 85.997-86.005	Green
		Ø 86.006-86.013	Blue

Mounting the connecting rod - piston assembly

Carry out the steps for removal described on pages 27 and 28 in reverse order.

Figure 53




117694

NOTE The connecting rod screws can be reused as long as the diameter of the thread is not less than 11.4 mm.

Mounting the piston rings

Figure 54




49029

To fit the piston rings (1) on the piston (2) use the pliers 99360184 (3).

The rings need to be mounted with the word "TOP" (4) facing upwards. Direct the ring openings so they are staggered 120° apart.

Fitting the connecting rod-piston assembly into the piston liners

Figure 55



Fit the half-bearings (1), selected as described on pages 19 to 24, both on the connecting rod and on the stand.



If the cap (1) is fitted upsidedown, the connecting rod should be discarded.

NOTE As spares, class A pistons are provided and can be fitted also to cylinder barrels belonging to class B.

Fit the connecting rod-piston assemblies (1) into the piston liners (2) using band 99360605 (1, Figure 56). Check the following:

- ☐ the openings of the split rings are offset by 120°;

Figure 57





Figure 56



- ☐ all pistons belong to the same class, A or B;
- ☐ ideogram stamped on the piston crown is placed toward the engine flywheel, or the cavity, on the piston cover, corresponds to the position of the oil spray nozzles.

Piston protrusion check

Once assembly is complete, check piston protrusion from cylinder barrels: it must be 0.873 to 1.177 mm.


- ☐ Connecting rod-piston assembly
- ☐ Marking area on the piston crown of ideogram specifying the assembly position and the selection class
- ☐ Connecting rod marking area (see Figure 52).

Checking assembly clearance of big end pins

To check the clearance proceed as follows:

connect the connecting rods to the relative main journals, place a length of calibrated wire on the latter.

Figure 58



Install the connecting rod caps (1) with half-bearings; tighten the connecting rod cap fixing screws (2) to 50 Nm (5 kgm) torque. By tool 99395216 (3), tighten the screws further at 90° angle.

Remove the caps and check the clearance by comparing the width of the calibrated wire with the scale calibration on the envelope containing the wire.

CYLINDER HEAD

Before dismounting cylinder head, check cylinder head for hydraulic seal by proper tooling; in case of leaks not caused by cup plugs or threaded plugs, replace cylinder head.


NOTE In case of plugs dismounting/replacement, on mounting, apply sealant Loctite 270 on plugs.

Dismounting the valves

NOTE Before dismounting cylinder head valves, number them in view of their remounting in the position observed on dismounting should they not have to be overhauled or replaced.

Intake valves are different form exhaust valves in that they have a notch placed at valve head centre.

Figure 59



Install and fix tool 99360264 (2) with bracket (4); tighten by lever (1) until cotters are removed (3); remove the tool (2) and the upper plate (5), the spring (6) and the lower plate (7).


Repeat the operation on all the valves.

Turn the cylinder head upside down and remove the valves (8).

Checking the planarity of the head on the cylinder block

Figure 60

(Demonstration)




The planarity (1) is checked using a ruler (2) and a thickness gauge (3). If deformations exist, surface the head using proper surface grinder; the maximum amount of material to be removed is 0.2 mm.

NOTE After leveling, make sure that valve sinking and injector protrusion are as described in the relative paragraph.

VALVE

Removing deposits and checking the valves


Figure 61



Remove carbon deposits using the metal brush supplied. Check that the valves show no signs of seizure or cracking.

Check the diameter of the valve stem using a micrometer (see Figure 62) and replace if necessary.

Figure 62



92841


MAIN DATA - VALVES AND VALVE GUIDES

* Values to be obtained after installing the valve guides

Check, by means of a micrometer, that valve stem diameters are as specified; if necessary, grind the valves seat with a grinder, removing the minimum quantity of material.

VALVE GUIDES

Figure 63



INSTALLATION DIAGRAM FOR VALVE GUIDES AND VALVES

47509

* Values to be obtained after installing the guide valves

Replacing of valve guides

Remove valve guides by means of tool 99360288.


Install by means of tool 99360288 equipped with part 99360294, which determines the exact installation position of valve guides into the cylinder heads; if they are not available, install the valve guides in the cylinder head so that they project out by mm 16.3 to 16.7 (Figure 63).

After installing the valve guides, smooth their holes with sleeker 99390310.

Replacing - Reaming the valve seats

To replace the valve seats, remove them using the appropriate tool.

Figure 64



Ream the valve seats (2) on cylinder head using tool (1).

NOTE Valve seats must be reamed whenever valves or valve guides are replaced or ground.


After reaming the valve seats, use tool 99370415, to make sure that the valve position, with respect to the cylinder head surface, is the following:

- ☐ -0.5 to -0.8 mm (recessing) of exhaust valves;
- ☐ -1.6 to 1.9 mm (recessing) of discharge valves.

REPLACING INJECTOR HOLDER CASES

Removal

Figure 65




To replace the injector case (2), act as follows:

- ☐ thread the case (2) with tool 99390804 (1).

Carry out operations described in the following figs. by fixing tools to the cylinder head by means of bracket A.


Figure 66



115888

- fasten extractor 99342149 (2) to case (3), by tightening the nut (1), and pull out the case from cylinder head.


Figure 67



45633

- Remove any residue (1), with tool 99390772 (2), from the cylinder head groove.


Figure 68



115889

- Lubricate sealing rings (3) and fit them to the case (4); fix tool 99360554 (2) to the cylinder head by means of bracket A, install the new case, tighten the screw (1), upsetting the case lower part.


Figure 69



115890

- Adjust the casing hole (3) with borer 99394043 (1) and guide bushing 99394045 (2).

Figure 70




115891

- Through mill 99394044 (1) and bushing 99394045 (2), ream the injector seat in the case (3), check the injector protrusion from the cylinder head plane which must be 1.2 to 1.5 mm.

Checking protrusion of injectors


Figure 71



47585

Using dial gauge (1), check the protrusion of the injector (2) which must be 1.2 to 1.5 mm.

Figure 72




114056

INSTALLATION DIAGRAM FOR INJECTOR CASE

TIMING GEAR Camshaft drive

Figure 73




TIMING CONTROL COMPONENT PARTS

1. Camshaft - 2. Bushing - 3. Pin - 4. Articulated rod -
5. Camshaft control gear - 6. Idler gear - 7. Twin idler gear -
8. Drive shaft driving gear.

Intermediate gear pin


Figure 74



Rated assembling play between idler gear bushings and pins:
 $0.040 \div 0.080$ mm.


Idler gear

Figure 75



Twin idler gear

Figure 76



Replacing the bushings


Bushings (1, Figures 75-76) can be replaced when they are worn. Put up the bushing, then grind it so as to bring it to a dimension of $\varnothing 65.010 \pm 0.10$ mm.

NOTE Bushing fitting in gears (2, Figures 75-76) must be performed in arrow direction, placing them as shown in figures.

Camshaft

Checking cam lift and pin alignment



Figure 77



47506

Place the camshaft (4) on the tailstock (1) and check cam lift (3) using a centesimal gauge (2); values are shown in table on page 9.

Figure 78




47507

When the camshaft (4) is on the tailstock (1), check alignment of supporting pin (3) using a centesimal gauge (2); it must not exceed 0.030 mm.

If misalignment exceeds this value, replace the shaft.

Figure 79




47505

In order to check installation clearance, measure bush inner diameter and camshaft pin (1) diameter; the real clearance is obtained by their difference.

If clearance exceeds 0.150 mm, replace bushes and, if necessary, the camshaft.

Figure 80




MAIN DATA - CAMSHAFT AND TOLERANCES

The surfaces of shaft supporting pin and cams must be extremely smooth; if you see any sign of seizing or scoring, replace the shaft and the relative bushes.

TOLERANCES	TOLERANCE CHARACTERISTIC	SYMBOL
ORIENTATION	Perpendicularity	\perp
POSITION	Concentricity or coaxial alignment	\odot
OSCILLATION	Circular oscillation	\nearrow
IMPORTANCE CLASS ASSIGNED TO PRODUCT CHARACTERISTICS		SYMBOL
CRITICAL		\odot
IMPORTANT		\oplus
SECONDARY		\ominus

Bushes

Figure 81



MAIN DATA - CAMSHAFT BUSHES AND RELATIVE BLOCK SEATS

* Bush inner diameter after installation


The bush surfaces must not show any sign of seizing or scoring; if they do replace them.

Measure the bush inner diameters with a baremeter and replace them, if the value measured exceeds the tolerance value. To take down and fit back the bushes, use the proper tool 99360487.

Use beater 99360505 to change bushings

Removal

Figure 82



114280

Use tool 99360505 (3) fitted as shown in fig. to remove bushings (2).


Accurately position beater during removal phase.

Fitting

For fitting, reverse operations performed for removal, with care to make lube hole (1), drilled on bushing, coincide with corresponding hole in housing.

VALVE SPRINGS

Figure 83




114215

MAIN DATA TO CONTROL EXHAUST AND DISCHARGE VALVE SPRING

Fitting the valves and oil seal ring

Figure 84




87051

Lubricate the valve stem and insert the valves in the respective valve guides; fit the lower caps (1). Use tool 99360292 to fit the oil seal (2) on the valve guides (3) of the exhaust valves; then, to fit the valves, proceed as follows.

NOTE Should valves not have been overhauled or replaced, remount them according to numbering performed on dismounting.

Intake valves are different from exhaust valves in that they have a notch placed at valve head centre.

Figure 85




86290

- ☐ fit springs (6) and the upper plate (5);
- ☐ apply tool 99360264 (2) and block it with bracket (4); tighten the lever (1) until cottons are installed (3), remove tool (2).

ROCKER SHAFT

Figure 86




114216

The camshaft eccentric elements control the 12 valve rocker arms directly. Valve control rocker arms are fitted directly on rocker arm shaft. Rocker arms slide directly on cam profiles by rollers. The other end operates on a crosspiece laid directly on the two valve rods. A pad is placed between rocker arm adjustment screw and crosspiece. Two lube ducts are machined inside rocker arms. Rocker arms shaft runs through the cylinder head; it must be removed to reach all units below.

Shaft

Figure 87




114217

MAIN DATA OF THE ROCKER ARM SHAFT

Check that the surface of the shaft shows no scoring or signs of seizure; if it does, replace it.


Rocker

Figure 88



114219

Figure 89



114218

The bush surfaces must not show any trace of scoring or excessive wear; otherwise, replace bushes or the whole rocker.

TIGHTENING TORQUES

PART		TORQUE	
		Nm	kgm
Pipe union for piston cooling nozzle	M12x1.5	35 ± 2	3.5 ± 0.2
Heat exchanger retaining screws		63 ± 7	6.3 ± 0.7
Plug		125 ± 15	12.5 ± 1.5
Spacer and oil sump fastening screws	M10x1.5x45	41.5 ± 3.5	4.1 ± 0.3
Gearcase fastening screws to cylinder block:	M10x1.25	41.5 ± 3.5	4.1 ± 0.3
	M12x1.75	63 ± 7	6.3 ± 0.7
	M8x1.25	23.5 ± 1.5	2.3 ± 1.5
Cylinder head fastening screw ♦			
First stage	pre-tightening	50	5
Second stage	pre-tightening	100	10
Third stage	angle closing		90°
Fourth stage	angle closing		75°
Rocker arm shaft fastening screw	M12x1.75x130	104.5 ± 10.5	10.4 ± 1
Locknut for rocker arm adjusting screw ♦		39 ± 5	3.9 ± 5
Electroinjector retaining bracket screws ♦	M10x1.5x40	39 ÷ 43	3.9 ÷ 4.3
Shoulder plate fastening screws to head ♦		23.5 ± 3.5	2.3 ± 0.3
Engine support bracket fastening screws to cylinder head		74 ± 8	7.4 ± 0.8
Gear fastening screws to camshaft •			
First stage	pre-tightening	25	2.5
Second stage	pre-tightening		45°
Phonic wheel fastening screws to distribution gear		8.5 ± 1.5	0.8 ± 0.1
Exhaust pipe fastening screws •			
pre-tightening		32.5 ± 7.5	3.2 ± 0.7
tightening		47.5 ± 2.5	4.7 ± 0.2
Connecting rod cap fastening screws: ♦	M12x1.25x69		
First stage	pre-tightening	50	5
Second stage	pre-tightening		90°
Engine flywheel fastening screws ♦	M18x1.5x72		
First stage	pre-tightening	120	12
Second stage	pre-tightening		90°
Flywheel pulley fastening screws to crankshaft ♦			
First stage	pre-tightening	70	7
Second stage	pre-tightening		50°
Main journal retaining screws ♦	M16x2x168		
First stage	pre-tightening	140	14
Second stage	pre-tightening		60° + 60°
♦ Lubricate with oil MOLYKOTE before assembly			
• Lubricate with graphitized oil before assembly			


PART	TORQUE	
	Nm	kgm
Damper flywheel fastening screws ♦	115 ± 15	11.5 ± 1.5
Idler gear pin fastening screws ♦		
First stage	30	3
Second stage	90°	
Idle gear link rod fastening screw	24.5 ± 2.5	2.4 ± 0.2
Oil pump fastening screw	24.5 ± 2.5	2.4 ± 0.2
Oil pump suction rose fastening screw	24.5 ± 2.5	2.4 ± 0.2
Front cover fastening screw to cylinder block	19 ± 3	1.9 ± 0.3
Control unit fastening screw to cylinder block	19 ± 3	1.9 ± 0.3
Fuel filter support fastening screw to cylinder head ♦	24.5 ± 2.5	2.4 ± 0.2
Screw securing the engine support to the wheelcase ♦		
First stage	100	10
Second stage	60°	
Turbo-compressor fastening screws and nuts •		
pre-tightening	35 ± 5	3.5 ± 0.5
tightening	46 ± 2	4.6 ± 0.2
Water pump fastening screw to cylinder block	24.5 ± 2.5	2.4 ± 0.2
Pulley fastening screw to hub	55 ± 5	5.5 ± 0.5
Rocker arm cover fastening screws	8.5 ± 1.5	0.8 ± 0.1
Thermostat box fastening screws to cylinder head	24.5 ± 2.5	2.4 ± 0.2
Automatic tightener fastening screws to cylinder block	45 ± 5	4.5 ± 0.5
Fixed tightener fastening screws to cylinder block	105 ± 5	10.5 ± 0.5
Fan support fastening screws to cylinder block	24.5 ± 2.5	2.4 ± 0.2
Starter fastening screws	44 ± 4	4 ± 0.4
Air heater on cylinder head	30 ± 3	5 ± 0.5
Hydraulic power steering pump gear fastening nut	105 ± 5	10.5 ± 0.5
Air conditioner compressor fastening screw to support	24.5 ± 2.5	2.4 ± 2.5
Alternator support superior fastening screw	71.5 ± 4.5	7.1 ± 0.4
Alternator bracket fastening screw to cylinder block	24.5 ± 2.5	2.4 ± 0.2
Water pipe unions	35	3.5
Water temperature sensor	32.5 ± 2.5	3.2 ± 0.2
♦ Lubricate with oil MOLYKOTE before assembly		
• Lubricate with graphitized oil before assembly		

PART		TORQUE	
		Nm	kgm
Flywheel rev sensor fastening screw		8 ± 4	0.8 ± 0.2
Camshaft rev sensor fastening screw		8 ± 4	0.8 ± 0.4
P.D.E solenoid connector fastening screw		1.62 ± 0.3	0.1 ± 0.3
Overboost pressure sensor fastening screw		8 ± 2	0.8 ± 0.2
Absolute pressure sensor fastening screw		22.5 ± 2.5	2.2 ± 0.2
P.W.M. control valve fastening screw/nut		8 ± 2	0.8 ± 0.2
Fuel/coolant temperature sensor		35	3.5
Coolant temperature indicator		23.5 ± 2.5	2.3 ± 0.2
Filter clogging sensor		10	1
Oil temperature switch		25 ± 1	2.5 ± 0.1
Oil pressure sensor		25 ± 1	2.5 ± 0.1
Electric wire fastening screw		8 ± 2	0.8 ± 0.2
Gear fastening screws to camshaft •	M14x2x50		
First stage	pre-tightening	40	
Second stage	pre-tightening		30°
Gear fastening screws to camshaft •	M14x2x50		
		$150 \div 184$	$15 \div 18.4$
Heater fastening screw	M8 x 60	24.5 ± 2.5	2.5 ± 0.2
	M8 x 90	24.5 ± 2.5	2.5 ± 0.2
Gear fastening screws to camshaft •	M10 x 1.25 x 20		
		$46.5 \div 52$	$4.65 \div 5.2$
Gear fastening screws to camshaft •			
		$46.5 \div 52$	$4.65 \div 5.2$
Alternator positive retaining nut	M8x1.25	12.5 ± 2.5	1.3 ± 0.3
Starter terminal nut 30	M10x1.5	21 ± 3.4	2.1 ± 0.3
Starter terminal nut 50	M5x0.8	3.6 ± 1	0.4 ± 0.1



SECTION 5

Tools


	Page
TOOLS	3
EQUIPMENT MODIFIED FOR ADAPTATION TO CURSOR 9 ENGINE	11

TOOLS**TOOL NO.****DESCRIPTION****99322230**


Rotary telescopic stand

99331043Adapter connectors 38 pin to 30 pin
(Part of 99368554)**99340051**


Extractor for crankshaft front gasket

99340054


Extractor for crankshaft rear gasket

99342149



Extractor for injector-holder

99346245

Tool to install the crankshaft front gasket

TOOLS**TOOL NO.****DESCRIPTION****99346260**


Tool to install the crankshaft back gasket

99360184Pliers for assembling and disassembling piston split rings
(105-106 mm)**99360264**


Tool for assembly and disassembly engine valves


99360288

Box wrench for block junction bolts to the underblock


99360292

Box wrench for block junction bolts to the underblock


99360294Tool to fit back valve guide
(to be used with 99360288)

TOOLS**TOOL NO.****DESCRIPTION****99360334**


Compression tool for checking the protrusion of cylinder liners

99360335Cylinder liner compression plate
(to be used with 99360334)**99360341**


Tool for rotating flywheel

99360500

Tool to lift crankshaft







99360505

Beater for tree removal and replacement bushings distribution







99360558

Tool for lifting and carrying shaft rockers







TOOLS


TOOL NO.	DESCRIPTION
99360585	 Swing hoist for engine disassembly assembly
99360605	 Belt to insert piston in cylinder liner (60 - 125 mm)
99360612	 Tool for positioning engine P.M.S.
99360613	 Tool for timing of phonic wheel on timing gear
99360703	 Tool to stop cylinder liners
99360706	 Tool to extract cylinder liners

TOOLS


TOOL NO.	DESCRIPTION
99360724	 Ring (115 mm) (to be used with 99360706)
99361042	 Rotary engine stand mounting bracket 99322230
99365054	 Tool for injector holder heading
99368542	 Series 8 keys to insert 14x18 (13-17-18-19-21-22-24-27-30 mm)
99327210	 PT - Plus
99368555	 30 to 19 pin adapter (component 99368554)

TOOLS




TOOL NO.	DESCRIPTION	
99368556		Adapter (5 m) for connection to PT01 testers diagnostic socket 30-pin (component 99368554)
99368558		Adapter (80 cm) for connection to PT01 testers diagnostic socket 30 poles Denox 2 (part of 99368554)
99370415		Base supporting the dial gauge for checking cylinder liner protrusion (to be used with 99395603)
99389833		14x18 plug wrench (20-120 Nm)
99389834		Torque screwdriver for calibrating the injector solenoid valve connector check nut
99390310		Valve guide sleeker

TOOLS**TOOL NO.****DESCRIPTION****99390772**


Tool for removing injector holding case deposits


99390804

Tool for threading injector holding cases to be extracted


99394043Reamer to rectify injector holder lower side
(to be used with 99394014)**99394044**Reamer to rectify injector holder lower side
(to be used with 99394015)**99394045**

Bushing (used with 99394043 and 99394044)


99395216Measuring pair for angular tightening with 1/2"
and 3/4" square couplings

TOOLS**TOOL NO.****DESCRIPTION****99395221**


Gauge for determining distance between tree distribution and high pressure pump

99395222

Gauge for determining distance between camshaft and gear for reference


99395223

Gauge for camshaft phasing

99395603

Dial gauge (0 - 5 mm)


EQUIPMENT MODIFIED FOR ADAPTATION TO CURSOR 9 ENGINE



For the permissible errors on the dimensions without tolerance and for other general specifications, see **IVECO** STD 10-2311

MAT.		COVER.		DRAWN UTS /		N°DRAWING 99360264				
All proprietary rights reserved by IVECO . This drawing shall not be reproduced or in any way utilised, for the manufacture or the component or unit herein illustrated and must not be released to other parties, without written consent. Any infringement will be legally pursued.	C/=0	I.S. 18-0011	Modifica per adeguamento		APPROVED		EXPER.		SIZE A4	
			attrezzo a motore		DATE		SHEET			
			CURSOR 9		SUPERSEDES					
					SCALE 1:1		IVECO			
					Q.TY 1					

Modification:




For the permissible errors on the dimensions without tolerance and for other general specifications, see **IVECO** STD 10-2311

Modification:

MAT.		COVER.	DRAWN UTS /	N°DRAWING 99360558	
All proprietary rights reserved by IVECO This drawing shall not be reproduced or in any way utilised, for the manufacture or the component or unit herein illustrated and must not be released to other parties, without written consent. Any infringement will be legally pursued.	C/=0	Modifica per adeguamento	APPROVED	EXPER.	SIZE A4
		attrezzo a motore	DATE	SHEET	
		CURSOR 9	SUPERSEDES		
		SCALE 1:1			
	Q.TY 1				
I.S. 18-0011					

02




Modification:

For the permissible errors on the dimensions without tolerance and for other general specifications, see **IVECO** STD 10-2311

MAT.		COVER.	DRAWN UTS /	N°DRAWING 99365054	
All proprietary rights reserved by IVECO . This drawing shall not be reproduced or in any way utilised, for the manufacture or the component or unit herein illustrated and must not be released to other parties, without written consent. Any infringement will be legally pursued.	C/=0	Modifica per adeguamento	APPROVED	EXPER.	SIZE A4
		attrezzo a motore	DATE	SHEET	
		CURSOR 9	SUPERSEDES		
		SCALE 1:1			
	Q.TY 1				
I.S. 18-0011					

02



Modification:

For the permissible errors on the dimensions without tolerance and for other general specifications, see **IVECO** STD 10-2311

MAT.		COVER.	DRAWN UTS /	N°DRAWING 99390804	
All proprietary rights reserved by IVECO This drawing shall not be reproduced or in any way utilised, for the manufacture or the component or unit herein illustrated and must not be released to other parties, without written consent. Any infringement will be legally pursued.		Modifica per adeguamento	APPROVED	EXPER.	SIZE A4
		attrezzo a motore	DATE	SHEET	
		CURSOR 9	SUPERSEDES		
	C/=0 I.S. 18-0011		SCALE 1:1		
			Q.TY 1		

02

Appendix

	Page
SAFETY PRESCRIPTIONS	3

SAFETY PRESCRIPTIONS

Standard safety prescriptions

Particular attention shall be drawn on some precautions that must be followed absolutely in a standard working area and whose non fulfillment will make any other measure useless or not sufficient to ensure safety to the personnel in-charge of maintenance.

Be informed and inform personnel as well of the laws in force regulating safety, providing information documentation available for consultation.

- ☐ Keep working areas as clean as possible, ensuring adequate aeration.
- ☐ Ensure that working areas are provided with emergency boxes, that must be clearly visible and always provided with adequate sanitary equipment.
- ☐ Provide for adequate fire extinguishing means, properly indicated and always having free access. Their efficiency must be checked on regular basis and the personnel must be trained on intervention methods and priorities.
- ☐ Organize and displace specific exit points to evacuate the areas in case of emergency, providing for adequate indications of the emergency exit lines.
- ☐ Smoking in working areas subject to fire danger must be strictly prohibited.
- ☐ Provide Warnings throughout adequate boards signaling danger, prohibitions and indications to ensure easy comprehension of the instructions even in case of emergency.

Prevention of injury

- ☐ Do not wear unsuitable cloths for work, with fluttering ends, nor jewels such as rings and chains when working close to engines and equipment in motion.
- ☐ Wear safety gloves and goggles when performing the following operations:
 - filling inhibitors or anti-frost
 - lubrication oil topping or replacement
 - utilization of compressed air or liquids under pressure (pressure allowed: ≤ 2 bar)
- ☐ Wear safety helmet when working close to hanging loads or equipment working at head height level.
- ☐ Always wear safety shoes when and cloths adhering to the body, better if provided with elastics at the ends.
- ☐ Use protection cream for hands.
- ☐ Change wet cloths as soon as possible
- ☐ In presence of current tension exceeding 48-60 V verify efficiency of earth and mass electrical connections. Ensure that hands and feet are dry and execute working operations utilizing isolating foot-boards. Do not carry out working operations if not trained for.
- ☐ Do not smoke nor light up flames close to batteries and to any fuel material.
- ☐ Put the dirty rags with oil, diesel fuel or solvents in anti-fire specially provided containers.

- ☐ Do not execute any intervention if not provided with necessary instructions.
- ☐ Do not use any tool or equipment for any different operation from the ones they've been designed and provided for: serious injury may occur.
- ☐ In case of test or calibration operations requiring engine running, ensure that the area is sufficiently aerated or utilize specific vacuum equipment to eliminate exhaust gas. Danger: poisoning and death.

During maintenance

- ☐ Never open filler cap of cooling circuit when the engine is hot. Operating pressure would provoke high temperature with serious danger and risk of burn. Wait until the temperature decreases under 50°C.
- ☐ Never top up an overheated engine with cooler and utilize only appropriate liquids.
- ☐ Always operate when the engine is turned off: whether particular circumstances require maintenance intervention on running engine, be aware of all risks involved with such operation.
- ☐ Be equipped with adequate and safe containers for drainage operation of engine liquids and exhaust oil.
- ☐ Keep the engine clean from oil tangles, diesel fuel and or chemical solvents.
- ☐ Use of solvents or detergents during maintenance may originate toxic vapors. Always keep working areas aerated. Whenever necessary wear safety mask.
- ☐ Do not leave rags impregnated with flammable substances close to the engine.
- ☐ Upon engine start after maintenance, undertake proper preventing actions to stop air suction in case of runaway speed rate.
- ☐ Do not utilize fast screw-tightening tools.
- ☐ Never disconnect batteries when the engine is running.
- ☐ Disconnect batteries before any intervention on the electrical system.
- ☐ Disconnect batteries from system aboard to load them with the battery loader.
- ☐ After every intervention, verify that battery clamp polarity is correct and that the clamps are tight and safe from accidental short circuit and oxidation.
- ☐ Do not disconnect and connect electrical connections in presence of electrical feed.
- ☐ Before proceeding with pipelines disassembly (pneumatic, hydraulic, fuel pipes) verify presence of liquid or air under pressure. Take all necessary precautions bleeding and draining residual pressure or closing dump valves. Always wear adequate safety mask or goggles. Non fulfillment of these prescriptions may cause serious injury and poisoning.

- ☐ Avoid incorrect tightening or out of couple. Danger: incorrect tightening may seriously damage engine's components, affecting engine's duration.
- ☐ Avoid priming from fuel tanks made out of copper alloys and/or with ducts not being provided with filters.
- ☐ Do not modify cable wires: their length shall not be changed.
- ☐ Do not connect any user to the engine electrical equipment unless specifically approved by Iveco.
- ☐ Do not modify fuel systems or hydraulic system unless Iveco specific approval has been released. Any unauthorized modification will compromise warranty assistance and furthermore may affect engine correct working and duration.

For engines equipped with electronic gearbox:

- ☐ Do not execute electric arc welding without having priority removed electronic gearbox.
- ☐ Remove electronic gearbox in case of any intervention requiring heating over 80°C temperature.
- ☐ Do not paint the components and the electronic connections.
- ☐ Do not vary or alter any data filed in the electronic gearbox driving the engine. Any manipulation or alteration of electronic components shall totally compromise engine assistance warranty and furthermore may affect engine correct working and duration.

Respect of the Environment

- ☐ Respect of the Environment shall be of primary importance: all necessary precautions to ensure personnel's safety and health shall be adopted.
- ☐ Be informed and inform the personnel as well of laws in force regulating use and exhaust of liquids and engine exhaust oil. Provide for adequate board indications and organize specific training courses to ensure that personnel is fully aware of such law prescriptions and of basic preventive safety measures.
- ☐ Collect exhaust oils in adequate specially provided containers with hermetic sealing ensuring that storage is made in specific, properly identified areas that shall be aerated, far from heat sources and not exposed to fire danger.
- ☐ Handle the batteries with care, storing them in aerated environment and within anti-acid containers. Warning: battery exhalation represent serious danger of intoxication and environment contamination.

Part 2
G-DRIVE CURSOR ENGINES

Section

General specifications

I

G-Drive Application

2

PREFACE TO USER'S GUIDELINE MANUAL

Section I describes engines F2C in their characteristics and general operation.

Section 2 is specific of use.

NOTE Part no. 2 is characterized by describing a particular industrial/agricultural application: G-Drive motors.

These engines are marketed as an assembly that is also equipped with the air/coolant and possibly air/air (intercooler) cooling device.

The description of this application gives the differences with the industrial application (given in the preceding Parts) and reference must be made to it for all repair and maintenance work.

UPDATING

Section	Description	Page	Date of revision

SECTION I**General specifications**

	Page
CORRESPONDENCE BETWEEN TECHNICAL CODE AND COMMERCIAL CODE	3
LUBRIFICATION	4
COOLING	5
<input type="checkbox"/> Description	5
<input type="checkbox"/> Operation	5
FUEL FEED	6
TURBOCHARGING	7

CORRESPONDENCE BETWEEN TECHNICAL CODE AND COMMERCIAL CODE


Technical Code	Commercial Code
F2CE9685A*E00I	CURSOR 87TE X

LUBRIFICATION

Engine lubrication is obtained with a gear pump driven by the crankshaft via gears. A heat exchanger governs the temperature of the lubricating oil. The oil filter, signalling sensors and safety valves are installed in the intercooler.

Figure 1

(Demonstration)



114244

Dropping oil
Pressure oil

LUBRICATION DIAGRAM

COOLING

Description


The engine cooling system is of the closed-circuit, forced circulation type. It consists mainly of the following components:

- ☐ expansion tank,
- ☐ a heat exchanger to cool down lubrication oil;
- ☐ a water pump with centrifugal system incorporated in the cylinder block;
- ☐ fan;
- ☐ a 2-way thermostat controlling the coolant circulation.

Operation

The water pump is actuated by the crankshaft through a poli-V belt and sends coolant to the cylinder block, especially to the cylinder head (bigger quantity). When the coolant temperature reaches and overcomes the operating temperature, the thermostat is opened and from here the coolant flows into the radiator and is cooled down by the fan.

Figure 2



COOLING SYSTEM DIAGRAM

119978


FUEL FEED

The Common Rail supply system is equipped with a special pump that maintains fuel at constant high pressure regardless from phase and cylinder under injection and accumulated in an common duct shared by all electric injectors.

Therefore, fuel at injection pressure, calculated by ECU, is always available at electric injection inlet.

When the solenoid valve of an injector is energized by ECU, in related cylinder the injection of fuel taken directly from the rail takes place.

Figure 3




TURBOCHARGING

The turbocharging system consists of:

- ☐ air filter;
- ☐ Turbocharger.

Figure 4













119980

SUPERCHARGING SYSTEM DIAGRAM

SECTION 2**G-Drive application**








	Page
GENERAL CHARACTERISTICS	3
ASSEMBLY CLEARANCE DATA	5
ENGINE CONNECTION AND DISCONNECTION FROM THE RADIATOR	11
MAINTENANCE PLANNING	13
MAINTENANCE PLANNING	15
<input type="checkbox"/> Recovery	15
<input type="checkbox"/> Inspection and/or maintenance interventions ..	15
OPERATIONS OUTSIDE THE PLAN	16
MAINTENANCE PROCEDURES	17
<input type="checkbox"/> Checks and controls	17
PRINCIPLE ELECTRICAL DIAGRAM	24
<input type="checkbox"/> Key to components	25
<input type="checkbox"/> Function symbols for the control panel	25
ENGINE INTERFACE BOX	26
<input type="checkbox"/> Description	26
<input type="checkbox"/> Connectors	27
EDC 7 UC3I ELECTRONIC CONTROL UNIT ..	30
<input type="checkbox"/> EDC control unit PIN-OUT	31

GENERAL CHARACTERISTICS













	Type	F2CE9685A*E001	
	Cycle	Diesel 4 strokes	
	Feeding	Turbocharged	
	Injection	Direct	
	N. of cylinders	6 on-line	
	Diameter	mm	117
	Stroke	mm	135
	Total displacement	cm ³	8710
	Compression ratio	1:15.9 ± 0.8	
	USA market		
	Maximum power (prime)	kW	251
	Maximum power (standby)	kW rpm	276 1800
	SUPERCHARGING		With intercooler
	Turbocharger type	HX 55	
	LUBRICATION		Forced by gear pump, relief valve single action oil filter
	Oil pressure (warm engine)		
	- idling	bar	-
	- peak rpm	bar	-
COOLING		Liquid	
Water pump control		Through belt	
Thermostat			
- start of opening		°C	85 ± 1.5













NOTE Data, features and performances are valid only if the setter fully complies with all the installation prescriptions provided by FPT.

Furthermore, the users assembled by the setter shall always be in conformance to couple, power and number of turns based on which the engine has been designed.













	Type	F2C	
	VALVE TIMING		
	opens before T.D.C.	A	17°
	closes after B.D.C.	B	31°
	opens before B.D.C.	D	48°
	closes after T.D.C.	C	9°
	For timing check		
	Running	X { mm mm	- -
		X { mm mm	0.35 to 0.45 0.55 to 0.65
	FEED	Bosch Common Rail with CRIN2 injectors and high pressure pump CP3.3	
	Nozzle type	DLA 137	
	Injection order	1 - 4 - 2 - 6 - 3 - 5	
	Injection pressure	bar	1800
	Injector calibration	bar	

ASSEMBLY CLEARANCE DATA












	Type	F2C
CYLINDER BLOCK AND CRANKMECHANISM COMPONENTS		mm
	Bores for cylinder liners: upper Ø1 lower	130.500 to 130.525 129.510 to 129.535
	Cylinder liners: external diameter: upper Ø2 lower length L	130.461 to 130.486 129.475 to 129.500 226,15 226.15
	Cylinder liners - crankcase bores upper lower	0.014 to 0.064 0.010 to 0.060
	External diameter Ø2	-
	Cylinder sleeve inside diameter Ø3A* inside diameter Ø3B* Protrusion X	117.000 to 117.012 117.010 to 117.022 0.035 to 0.065
* Selection class		
	Pistons: measuring dimension X external diameter Ø1A external diameter Ø1B pin bore Ø2	15 116.894 to 116.906 116.904 to 116.916 52.010 to 52.016
	Piston - cylinder sleeve A* B*	0.094 to 0.118 0.094 to 0.118
* Selection class		
	Piston diameter Ø1	-
	Pistons protrusion X	0.873 to 1.117
	Gudgeon pin Ø3	51.994 to 52.000
	Gudgeon pin - pin housing	0.010 to 0.022












	Type	F2C	
		mm	
	Piston ring grooves	X1	3,120 ÷ 3,140
		X2	3.120 to 3.140
		X3	2.550 to 2.570
		X3	4.020 to 4.040
	Piston rings: trapezoidal seal	S1	3.000
	lune seal	S2	2.470 to 2.500
	milled scraper ring with slits and internal spring	S3	3.970 to 3.990
	Piston rings - grooves	1	-
		2	0.050 to 0.100
		3	0.030 to 0.070
	Piston rings		-
	Piston ring end gap in cylinder liners	X1	0.3 to 0.4
		X2	0.60 to 0.75
		X3	0.35 to 0.65
	Small end bush housing	Ø1	55.700 to 55.730
	Big end bearing housing	Ø2	85.987 to 86.013
	Selection classes	1	85.987 to 85.996
		2	85.997 to 86.005
		3	86.006 to 86.013
	Small end bush diameter outside	Ø4	55.780 to 55.820
	inside	Ø3	52.015 to 52.030
	Big end bearing shell	S	1.994 to 2.002
	Red		2.002 to 2.010
	Green		2.010 to 2.018
	Yellow ●		
	Small end bush - housing		0.05 to 0.08
	Piston pin - bush		0.015 to 0.036
	Big end bearing		0.127 - 0.254 - 0.508
	Connecting rod weight	A	g
		A	3450 to 3470
		B	3471 to 3490
		C	3491 to 3510






● Fitted in production only and not supplied as spares

	Type	F2C	
		mm	
	Measuring dimension X	X	125
	Max. connecting rod axis misalignment tolerance	=	0.08
	Main journals	Ø1	92.970 to 93.000
	- nominal		92.970 to 92.980
	- class	1	92.980 to 92.990
	- class	2	92.990 to 93.000
	- class	3	
	Crankpins	Ø2	81.915 to 81.945
	- nominal		81.915 to 81.925
	- class	1	81.925 to 81.935
	- class	2	81.935 to 81.945
	- class	3	
	Main bearing shells	S1	2.968 to 2.978
	Red		2.978 to 2.988
	Green		2.988 to 2.998
	Yellow*		
	Big end bearing shells	S2	1.994 to 2.002
	Red		2.002 to 2.010
	Main bearing housings	Ø3	99.000 to 99.030
	- nominal		99.000 to 99.009
	- class	1	99.010 to 99.019
	- class	2	99.020 to 99.030
	Bearing shells - main journals		0.050 to 0.090
	Bearing shells - big ends		0.040 to 0.080
	Main bearing shells		0.127 - 2.254 - 0.508
	Big end bearing shells		0.127 - 2.254 - 0.508
	Main journal, thrust bearing	X1	39.96 to 40.04
	Main bearing housing, thrust bearing	X2	38.94 to 38.99
	Thrust washer halves	X3	3.38 to 3.43
	Crankshaft end float		0.10 to 0.30
	Alignment	=	1 - 2
	Ovalization	○	1 - 2
	Taper	>	1 - 2

* Fitted in production only and not supplied as spares


 Type	F2C
CYLINDER HEAD - VALVE TRAIN	mm
 <p>Valve guide housings in cylinder head</p> <p>Ø 1</p>	12.9800 to 12.997
 <p>Valve guide</p> <p>Ø 2 Ø 3</p>	8.023 to 8.038 13.012 to 13.025
 <p>Valve guides - housings in the cylinder heads</p>	0.015 to 0.045
 <p>Valve guide</p>	0.2 - 0.4
 <p>Valves:</p> <p>Ø 4 α</p> <p>Ø 4 α</p>	7.970 to 7.985 60° 30' ± 7' 30" 7.970 to 7.985 45° $^{+15}_{-0}$
 <p>Valve stem and its guide</p>	0.040 to 0.070
 <p>Valve seat in head</p> <p>Ø 1 Ø 1</p>	41.985 to 42.020 40.985 to 41.020
 <p>Outside diameter of valve seat; angle of valve seat in cylinder head:</p> <p>Ø 2 α</p> <p>Ø 2 α</p>	$^{0'}_{-0.5'}$ 42.060 to 42.075 60° - 30' $^{0'}_{-0.5'}$ 41.060 to 41.075 45° - 30'
 <p>Recessing of valve</p> <p>X X</p>	0.5 to 0.8 1.6 to 1.9
 <p>Between valve seat and head</p>	0.040 to 0.090

	Type	F2C	
		mm	
	Valve spring height:	A	B
	free height	70.77	-
	under a load of:		
	N 460 ± 23 H1A } N 460 ± 22 H1B } N 740 ± 33 H2A } N 731,4 ± 42 H2B }	51	39
	Injector protrusion	X	1.2 to 1.5
	Camshaft bushing housing in the cylinder head: I ⇒ 7	Ø	69.000 to 69.030
	Camshaft bearing journals: I ⇒ 7	Ø	64.924 to 64.940
	Outer diameter of camshaft bushings:	Ø	69.090 to 69.130
	Inner diameter of camshaft bushings:	Ø	65.080 to 65.116
	Bushings and housings in the cylinder head		0.060 to 0.130
	Bushings and bearing journals		0.14 to 0.192
	Cam lift:		7.5138 8.2108
	Rocker shaft	Ø I	31.964 to 31.980

	Type	F2C
		mm
	Bushing housing in rocker arms	32.025 to 32.041
		32.025 to 32.041
	Between bushings and housings	0.045 to 0.077
		0.045 to 0.077
TURBOCHARGER		
Type		HX55
End float		-
Radial play		-

ENGINE CONNECTION AND DISCONNECTION FROM THE RADIATOR

Figure 1



119971



Removal

Prepare a suitable container near the pipe coupling (12) to recover the coolant. Detach and remove the pipe couplings (12) and (7) operating the clamps.

Detach and remove from the engine and from the radiator the pipes (5) and (11) operating on their collars.

Remove the protection grilles (10) and the guard (8) of the fan operating on their fasteners.

Unscrew the engine side retaining nut of the fabric (6) so as to release it.

Suitably lock the radiator group (9), then detach it from the basement operating on the fasteners on both sides.

Detach the air filter from the engine (1) operating from collar (4) and the support (16) operating on the fasteners (15) after detaching the oil vapour hose (3) and the pipe coupling (4) from the turbocharger.

Remove the screws which fasten the engine supports to the basement and detach the engine.

To access the engine belt, it is necessary to remove the protection guard (13), unscrewing the screws (14).



Refitting

For the connection operation repeat the described operations for the disconnection on the contrary and apply the following instructions:

- ☐ to control the engine elastic supports and to replace them in case of deterioration ;
- ☐ to control that the exhaust pipes are not deteriorated or are going to deteriorate; in this case you shall replace them;
- ☐ to clamp the screws and/or nuts to the described couple;
- ☐ to fill the cooling system with cooling liquid;
- ☐ to carry out bleeding operation from the fuel supply system as described in the suited paragraph.
- ☐ to control engine oil level;
- ☐ to carry out the tests and controls as described in the suited chapter.

MAINTENANCE PLANNING

MAINTENANCE PLANNING

Recovery

To ensure optimised working conditions, in the following pages we are providing instructions for the overhaul control interventions, checks and setting operations that must be performed on the engine at due planned dates.

The frequency of the maintenance operations is just an indication since the use of the engine is the main characteristic to determine and evaluate replacements and checks.

It is not only allowed but recommended that the staff in charge of the maintenance should also carry out the necessary maintenance and controlling operations even if not being included in the ones listed here below but that may be suggested by common sense and by the specific conditions in which the engine is run.

Inspection and/or maintenance interventions

Intervention type	Frequency (hours)
Engine	
Engine visual inspection	Daily
Check for water in the filter and prefilter	Daily
Engine oil change	Every 600 hours
Engine oil filter change	Every 600 hours
Fuel prefilter change	Every 300 hours
Fuel filter change	Every 300 hours
Changing the Blow-by filter	Every 600 hours
Check condition of water pump/alternator control belt	Every 1200 hours
Check-up of EDC system by diagnostics tool	-
Check valve lash and adjust, if required	Every 1200 hours
Dry air filter change and container cleaning	-

NOTE The maintenance operations are valid only if the setter fully complies with all the installation prescriptions provided by FPT.

NOTE Low temperature diesel EN 590 specifications distinguish different classes of diesel fuel, identifying the characteristics of those best suited to low temperatures. It is entirely up to the Oil companies to comply with these regulations, which foresee that fuels suited to the climatic and geographic conditions of the various Countries be distributed.

OPERATIONS OUTSIDE THE PLAN

Daily checks

It is a good habit to execute, before engine start, a series of simple checks that might represent a valid warranty to avoid inconveniences, even serious, during engine running. Such checks are usually up to the operators and to the vehicle's drivers.

- Level controls and checks of any eventual leakage from the fuel, cooling and lubricating circuits.
- Notify the maintenance if any inconvenience is detected or if any filling is necessary.

After engine start and while engine is running, proceed with the following checks and controls:

- check presence of any eventual leakage from the fuel, cooling and lubricating circuits.
- Verify absence of noise or unusual rattle during engine working.
- Verify, using the vehicle devices, the prescribed pressure temperature and other parameters.
- Visual check of fumes (colour of exhaust emissions)
- Visual check of coolant in the expansion tank

NOTE Early air filter clogging is usually due to environmental conditions. For this reason, the filter should be changed if clogging is signalled by the related sensor, regardless of the prescriptions that shall be observed if no specific indications have been provided.

Every year – Before winter

and possibly when a maintenance operation is carried out

Check the antifreeze percentage in the engine cooling water

Every two year

and possibly when a maintenance operation is carried out

Change engine coolant

MAINTENANCE PROCEDURES


Checks and controls

Engine oil level check

The check must be executed when the engine is disconnected and possibly cool.

The check can be made using the specially provided flexible rod (1).

Figure 2 (Demonstration)



145841


Draw off the rod from its slot and check that the level is within the etched tags of minimum and maximum level.

Whether it should be difficult to make the evaluation, proceed cleaning the rod using a clean cloth with no rag grinding and put it back in its slot. Draw it off again and check the level.

In case the level results being close to the tag showing minimum level, provide filling lubrication of the engine's components.

Always be sure to add an oil with the same characteristics than that contained in the cup. Are not allowed mixing which would not provide proper lubrication of internal engine parts.

Figure 3 (Demonstration)



145842

Top up via the tappet cover cap (2). When filling, remove the dipstick (1) to facilitate the flow of oil.



The engine oil is highly polluting and harmful.



In case of contact with the skin, rinse well with water and detergent.

Adequately protect the skin and the eyes, operate in full compliance with safety regulations.

Disposal must be carried out properly, and in full compliance with the law and regulations in force.

Check of fuel system

The check must be executed both when the engine disconnected and when it is running.

The check operation consists in examining the fuel pipelines running from the tank to the pre-filter (if provided in the specific equipment), to the filter, to the injection pump and to the injectors.

Cooling system check

The check must be executed both when the engine disconnected and when it is running.

Check the pipes from the engine to radiator, and from the expansion tank and vice versa; check for any leaks and inspect the pipes, in particular near the connection clamps.

Verify that the radiator is clean, the correct working of the fan flywheels, the presence of any leakage from the connectors, from the manifold and from the radiating unit.



Due to the high temperatures achieved by the system, do not operate immediately after the engine's disconnection, but wait for the time deemed necessary for the cooling.

Protect the eyes and the skin from any eventual high pressure jet of cooling liquid.

The density of the cooling liquid must be checked any how every year before winter season and be replaced in any case every two year.



In case of new filling, proceed bleeding system, through the bleeds on the engine.

If bleeding of the system is not carried out, serious inconvenience might be caused to the engine due to the presence of air pockets in the engine's head.

Lubricating system check

The check must be executed both when the engine disconnected and when it is running.

Verify the presence of any oil leakage or blow-by from the head, from the engine pan or from the heat exchanger.



The engine oil is highly polluting and harmful.



In case of contact with the skin, rinse well with water and detergent.

Adequately protect the skin and the eyes, operate in full compliance with safety regulations.

Disposal must be carried out properly, and in full compliance with the law and regulations in force.


Check for water in the fuel filter and prefilter



The components of the system can be damaged very quickly in presence of water or impurity within the fuel.

Take prompt action on the filter to drain off the water in the fuel circuit.

Figure 4




145883

The drain screw (1) for draining off any water that may be contained in the fuel is located on the fuel filter support (2).

Place a container underneath the filter and slightly loosen the screw. Drain the water eventually contained in the filter's bottom.

Lock the screw (1) as soon as fuel starts bleeding.

Figure 5



145884


Unhook the electrical connection (2) from the pre-filter (1) and place a container under the pre-filter.

Drain off the water from the fuel pre-filter (1) using the drain (3) located beneath it.

During this process take care the fuel does not damage the sensor.

Engine oil change

Figure 6



We recommend to carry out the oil drainage when the motor is hot.



Warning: We recommend to wear proper protections because of high motor service temperature.

The motor oil reaches very high temperature: you must always wear protection gloves.

- ☐ Place a proper container for the oil collecting under the pan connected with the drain plug (3).
- ☐ Unscrew the plug (3) and then take out the control dipstick (1) and the inserting plug (2) to ease the downflow of the lubrication oil.



The oil motor is very pollutant and harmful.

In case of contact with the skin, wash with much water and detergent.



Protect properly skin and eyes: operate according to safety rules.

Dispose of the residual properly following the rules.


- ☐ After draining completely, screw on the plug (3) under the sump and tighten it to the prescribed torque.
- ☐ Add the specified quantity of recommended engine oil through the filler (2) of the tappets cover.

NOTE Use only the recommended oil or oil having the requested features for the correct motor functioning. In case of topping up, don't mix oils having different features. If you don't comply with these rules, the service warranty is no more valid.

- ☐ Check the level through the dipstick until when the filling is next to the maximum level notch indicated on the dipstick.

Engine oil filter change

Figure 7



Drain the oil as described in the section "Changing the engine oil".

Remove the oil filter (1).

NOTE Warning: the oil filter contains inside a quantity of oil of about 1 kg.



Place properly a container for the liquid.

Warning: avoid the contact of skin with the motor oil: in case of contact wash the skin with running water.


The motor oil is very pollutant: it must be disposed of according to the rules.

NOTE Before refitting the new cartridge, wet seal using engine oil.

Lock oil filter (1) by hand till contact to support and then lock by $\frac{3}{4}$ of a rev. at prescribed tightening torque; pour oil in engine as described in "Engine oil change" chapter.

Replace fuel tank prefilter

Figure 8



Disconnect electric connector (4). Unlock prefilter (1) and change it. Before refitting a new cartridge, wet seal with fuel oil or engine oil. Lock cartridge by hand till in contact with support, then lock it by $\frac{3}{4}$ of a rev. at predefined tightening torque.



At change, filter cartridge must not be prefilled to prevent circulating dirt that could damage injector/pump system components.

Bleed air from the fuel as described below.

To bleed, pump with the hand pump (3) on the pre-filter (1) until fuel free of air flows from the loosened bleed screw (2).


Apply a transparent tube to the bleed screw (2) to facilitate the operation and above all to avoid that the bled fuel dangerously fouls the engine.

After operation, tighten the bleed screw (2).

Start the engine and allow it to run for a few minutes to expel any remaining air.

Fuel filter change

Figure 9



During this operation don't smoke and don't use free flames.

Avoid to breathe the vapors coming from filter.



After filters replacement the supply equipment deaeration must be carried out.

Unscrew the fuel filter cartridge (2).

Before fitting the new cartridge, wet seal with fuel or engine oil.

Lock the new one by hand and carefully check that rubber seal and contact surface are clean and in perfect conditions.

Lock cartridge by hand till contact with support and then lock it for $\frac{3}{4}$ of a rev. at prescribed tightening torque.



When replacing the filter cartridge (2) do **NOT** fill it.


This operation is banned to avoid impurities entering into the circuit, which would damage the injector/pump system components.

Bleed air from the fuel as described below.

Fuel bleeding

Loosen the bleed screw (1) connecting the drainage by a transparent flexible hose to a suitable container.

Figure 10




With the hand pump (2) of the fuel pre-filter (1) pump until fuel completely free of air bubbles flows from the bleed screw.

After the operation, tighten the bleed screw.

Start the engine and allow it to run at minimum for a few minutes to expel any remaining air.


Changing the Blow-by filter

Figure 11



Unlock screws (2) and remove cover (1). Remove the centrifugal filter (3) underneath and replace it.

Figure 12




Install blow-by body (1) with related seal and lock screws (2) at required torque.

Install cover (3) and lock screws (4) at required torque.

Check of water pump/alternator control belt condition

Figure 13



Visually check that belt (4) is not worn out or broken; change it as described below, if required.

NOTE To be able to work on the engine belt you first need to remove the protective casing (if applicable) by unscrewing the screws.

Use appropriate equipment (5) on the belt tensioner (6) in the direction shown by the arrow and extract the belt (4) from the pulleys of the alternator (1), of the coolant pump (2) and from the idler pulleys (3).

Replace the worn belt with a new one.

Place the belt on the pulleys and the guide rollers.

Place the automatic tightener in order to key the belt in the functioning position.


Further adjustments are not required.

Valve lash check a adjustment

For correct operation, follow instructions contained in related chapter in section 3 – Industrial Application.

Cleaning the air filter

Figure 14



Only proceed with the engine stopped.

- ☐ Remove the filter cover (3) after first unscrewing the locking handle (2).
- ☐ Remove the external cartridge (1). During this operation, take care to ensure that no dust get into the sleeve.
- ☐ Check that there is no dirt. If there is, clean the filter element as indicated below.
- ☐ Blow dry compressed air through the filter element, from the inside outward (maximum pressure 200 kPa). Do not use detergents; do not use diesel.
- ☐ Never use tools to beat the filter element, and check its condition before replacing it.
- ☐ Replace the filter if any breakages or tears are found.
- ☐ Check that the gasket at its base is in good condition.
- ☐ Reassemble by repeating the above operations in reverse order.

NOTE Take care to ensure that the parts are reassembled correctly. Imperfect assembly might result in unfiltered air being sucked into the engine, causing serious damage.

Air filter replacement

Refer to the instructions provided for air filter cleaning.


Change coolant

Only proceed with the engine stopped and at a low temperature, so as to avoid the risk of burning.

- ☐ Provide suitable containers to ensure that no coolant is dispersed into the environment.
- ☐ Loosen the seal elements, remove the sleeves connecting the engine circuit to the heat exchanger and wait until it has emptied completely. When empty, repair the circuit making sure that the sleeves are perfectly sealed.
- ☐ Fill up the circuit.
- ☐ Refill the engine and the heat exchanger until complete top up.
- ☐ With the filler cap open, start the engine and keep it idling for nearly one minute. This phase facilitates the cooling liquid air bleed.
- ☐ Stop the engine and top up again.

PRINCIPLE ELECTRICAL DIAGRAM

Figure 15



Key to components

BAT	Starter battery 12V
M	Starter motor
G	Battery charger alternator
RFC	Fuel filter heating resistor
TRFC	Fuel filter heating thermostat
TPAC	Water in the fuel filter transmitter
TBLA	Low engine water level transmitter
TPO	Engine oil pressure switch
TBPO	Low engine oil level pressure switch
TTA	Engine water temperature transmitter
TCE	No fuel transmitter (option)
TBLC	Float for fuel level
TS	Engine water heater thermostat
EDC	Engine electronic control unit
TATA	High engine water temperature thermostat
SI	Control panel - engine interface box

Function symbols for the control panel

ENGINE WATER TEMPERATURE THERMOMETER



LOW ENGINE OIL PRESSURE VISUAL WARNING



ENGINE OIL PRESSURE GAUGE



STARTING THE ENGINE (+50)



NO BATTERY CHARGING VISUAL WARNING



LOW ENGINE WATER LEVEL VISUAL WARNING



CAPTIVE KEY POSITIVE (+15)



WATER IN THE FUEL FILTER VISUAL WARNING



HIGH ENGINE WATER TEMPERATURE VISUAL WARNING



CAN LINE



CONTROL PANEL POWER SUPPLY




ENGINE PRE-HEATING



FUEL LEVEL VISUAL WARNING



NO FUEL VISUAL WARNING (OPTION)

ENGINE INTERFACE BOX**Description****Figure I 6**


107437

LIST OF COMPONENTS

K1. Power relay with key inserted (+ I5) - K2. Starting phase signal relay - K3. Starting relay - K4. Relay for pre-heating resistance enabling - JP1. Jumper to select frequency (jumper on 1-2= 60Hz - jumper on 2-3= 50Hz) - JP2. Jumper for operating mode selection (bond on 1-2= diagnosis - bond on 2-3= normal operation) - JP3. Jumper to select cold start signal connection (1-2= connected - 2-3= disconnected) - JP4. Jumper to select heat. function for cold starting (1-2= connected - 2-3= disconnected) - JP5. Jumper for Can Line selection (1-2= Can Line connected - 2-3= Can Line not connected) - JP6. Not used - JP8. Not used - BP1. Switch for blink-code signal request - LD1. LED signalling blink/code - F1. 10A fuse for starting engine - F2. 3A fuse for diagnostics - F3. 20A protection fuse for pre-heating resistance - F4. 30A fuse for electronic control unit - F5. 10A fuse for control panel - F6. 5A fuse for cut-in +I5 ON ECU - F7. 20A protection fuse for fuel filter heater - F8. Not used - F9. Not used - J1. Connector for power connections - J2. Connector for interface with engine control unit - J3. Connector for interface with control panel - J7. Connector for interface with control panel - J9. Connector for interface with control panel.

Connectors

Figure 17



CONNECTOR J1 on engine – control panel interface box for power supply (GECURSOR300E/350E/400E)

- 1 To terminal 50 of starter motor
- 2 Supply from F3 for fuel filter heating resistance
- 3 Battery negative
- 4 Direct positive to battery
- 5 Spare
- 6 Spare

CONNECTOR J2 on engine – control panel interface box for EDC ECU connections

1	+15 from ignition key
2	12 jumper
3	Negative signal from oil low pressure pressure switch
4	Signal from water temperature sensor
5	Negative signal from water high temperature pressure switch
6	Signal from fuel zero level transmitter
7	Fuel low level signal
8	Supply of water presence in fuel sensor
9	Signal from water presence in fuel sensor
10	Ground of water presence in fuel sensor
11	Jumper with 37
12	Jumper with 2
13	Positive +30
14	Positive +30
17	Supply of water low level sensor
18	Signal from water low level sensor
19	Ground of water low level sensor
20	No recharge from alternator signal
22	Ground for diagnosis lamp
23	Positive signal for diagnosis lamp
25	Torque limiting resistance
27	Line K - diagnosis EDC
29	Negative signal from EDC system diagnostic switch
31	Signal from oil pressure sensor
32	Negative signal from water heater thermostat
33	Ground
37	Jumper with 11
40	Positive signal for excitation of contactor of fuel filter heater
41	Positive +30
42	Positive +30
46	Ground
47	Ground
48	Positive for cold start lamp
49	Positive for excitation of pre-heating contactor
50	Pre-heating contactor ground
53	Negative signal from EDC system diagnostic switch
54	Engine revs signal from EDC control unit
55	Line CAN L
56	Line CAN H

NOTA Pins 1 and 2 of EDC ECU are connected to battery negative

CONNECTOR J3 inside the engine interface box for signals to control panel


- | | |
|----|--|
| 1 | Free |
| 2 | From the engine water temperature transmitter for signal to thermometer on control panel |
| 3 | From the low engine oil pressure switch for visual warning on control panel |
| 4 | From engine oil pressure switch for signal to pressure gauge on control panel |
| 5 | Free |
| 6 | To the key switch (+50) on control panel |
| 7 | From the alternator for battery charging visual indicator on control panel |
| 8 | From the low engine water level transmitter for visual warning on control panel |
| 9 | +15 |
| 10 | From the water in fuel filter transmitter for visual warning on control panel |
| 11 | Free |
| 12 | Free |

CONNECTOR J7 inside the engine interface box for signals to control panel

- | | |
|---|--|
| 1 | From the engine coolant high temp. thermostat for visual signal on control panel |
| 2 | CAN line L to the control panel |
| 3 | Positive to power control panel |
| 4 | Negative to power control panel |
| 5 | CAN line H to the control panel |
| 6 | From the engine water heater thermostat to the control panel |
| 7 | From the fuel level transmitter for visual warning on control panel |
| 8 | From the no fuel transmitter (opt) |

CONNECTOR J9 inside the engine interface box

- | | |
|----|---|
| 1 | Cold start signal (option) if jumper JP3 set on 1-2 |
| 2 | Cold start signal (option) if jumper JP3 set on 1-2 |
| 3 | Cold start heater relay (option) if jumper JP4 set on 1-2 |
| 4 | Cold start heater relay (option) if jumper JP4 set on 1-2 |
| 5 | Free |
| 6 | Free |
| 7 | Free |
| 8 | Free |
| 9 | Free |
| 10 | Free |

EDC 7 UC31 ELECTRONIC CONTROL UNIT**Figure 18**


102373

A. Electro-injector connector - B. Chassis connector - C. Sensor connector

EDC control unit PIN-OUT

Chassis connector "B"

Figure 19



ECU Pin	Cable	Function
2	7151	Positive +30
3	7151	Positive +30
5	0150	Ground
6	0150	Ground
8	7151	Positive +30
9	7151	Positive +30
10	0150	Ground
11	0150	Ground
12	8885	Positive for excitation of pre-heating contactor
13	0000	Ground
21	-	Jumper with 74
22	5535	Positive signal for diagnosis lamp
29	0000	Ground
30	0535	Ground for diagnosis lamp
33	5584	Engine revs signal from EDC control unit
34	6109	Line CAN L
35	6108	Line CAN H
36		Positive signal for excitation of contactor of fuel filter heater
40	7731	+15 from ignition key
56	5553	Positive for cold start lamp
62	0021	Torque limiting resistance
66	5120	Torque limiting resistance
74	-	Jumper with 21
75	0094	Pre-heating contactor ground
85	0156	Negative signal from EDC system diagnostic switch
89	2298	Line K - diagnosis EDC

