

Kawasaki


Parts List

FA-76D (314505)

FA-76D (314506)

4 cycle air-cooled
gasoline engine


FA210 FA76 FA130 FA210 FA76 FA130
FA76 FA130 FA210 FA76 FA130 FA76
FA130 FA210 FA76 FA130 FA210 FA76
FA210 FA76 FA130 FA210 FA76 FA130
FA76 FA130 FA210 FA76 FA130 FA76
FA130 FA210 FA76 FA130 FA210 FA76
FA210 FA76 FA130 FA210 FA76 FA130
FA76 FA130 FA210 FA76 FA130 FA76
FA130 FA210 FA76 FA130 FA210 FA76
FA210 FA76 FA130 FA210 FA76 FA130
FA76 FA130 FA210 FA76 FA130 FA210
FA130 FA210 FA76 FA130 FA210 FA76



Ref.No.	Part No.	Part Name	Quantity						Remarks
			05A						
1	314501-1111A	HEAD, cylinder	1						
2	314501-1121A	GASKET, head	1						
3	186G0640	BOLT (6x40)	8						
4	314501-1231B	COVER, inspection	1						
5	314501-1232A	GASKET	1						
6	186B0612	BOLT (6x12)	3						
7	314506-1321A	COVER, air cleaner	1						
8	314595-1312A	ELEMENT	1						
9	314595-1313A	PLATE, air cleaner	1						
10	314506-1311A	CASE, air cleaner	1						
11	314413-1316A	BOLT	2						
12	314501-1332A	GASKET	1						
13	702A071000	TUBE, rubber	1						ℓ=140mm
14	314401-1341A	PIPE	1						
15	314505-1410A	MUFFLER ASS'Y	1						
16	395000-1442A	GASKET	1						
17	171G0616	STUD	2						
18	311B0600	NUT (6mm)	2						
19	410B0600	WASHER	2						
20	314506-1611A	CASE, spiral	1						
21	186B0610	BOLT (6x10)	4						
22	314584-1631A	COVER, cylinder head	1						
23	314501-1632A	COVER, cylinder	1						
24	241B0510	SCREW (5x10)	1						
25	314501-2110A	VALVE, inlet	1						
26	314501-2112A	VALVE, exhaust	1						
27	314501-2113A	SPRING, valve	2						
28	314501-2116A	SEAT, spring	2						
29	314501-2211A	TAPPET	2						
30	314501-2311B	GEAR, cam	1						
31	314501-3111A	PISTON	1						
32	314598-3010B	PISTON RING SET	1						
33	314501-3121A	PIN, piston	1						
34	314501-3122A	RING, snap	2						
35	314598-3211A	SHAFT, crank	1						
36	314501-3240A	CONNECTING ROD ASS'Y	1						
37	314501-3245A	•BOLT, connecting rod	2						
38	314501-3248A	WASHER, lock	1						
39	314501-3249A	ARM, splash	1						
40	314501-3430A	RECOIL STARTER ASS'Y	1						Fig. R-1
41	314599-1650A	SCREEN	1						
42	187B0610	BOLT (6x10)	3						

Ref.No.	Part No.	Part Name	Quantity						Remarks
			05A						
43	314501-4110D	CRANK CASE ASS'Y	1						
44	314501-4211B	•BEARING, plain	1						
45	3145V2-7214A	•GASKET	2						
46	130B1014	•BOLT (10x14)	2						
47	314501-4231A	SEAL, oil	1						
48	551A0612	PIN, dowel	2						
49	314501-4120A	SIDE BASE ASS'Y	1						
50	314501-4211B	•BEARING, plain	1						
51	314501-4124A	GASKET	1						
52	186B0622	BOLT (6x22)	6						
53	314501-4231A	SEAL, oil	1						
54	314502-5110A	GOVERNOR ASS'Y	1						
55	314401-5121A	SLEEVE, governor	1						
56	314501-5122C	TIP, governor	1						
57	554A0600	PIN, snap	1						
58	410B0600	WASHER	1						
59	314401-5135A	WASHER	1						
60	314598-5211C	ARM, governor	1						
61	112B0625	BOLT (6x25)	1						
62	311B0600	NUT (6mm)	1						
63	411B0600	WASHER	1						
64	314501-5231A	LINK, governor	1						
65	314501-5232A	SPRING, link	1						
66	314502-5314A	SPRING, governor	1						
67	314501-5311A	LEVER, control	1						
68	314501-5335B	BRACKET	1						
69	314501-5389A	PLATE	1						
70	314401-5383A	WASHER	1						
71	314401-5385A	NUT	1						
72	314401-5388A	SPRING	1						
73	314401-5321B	SPRING	1						
74	214B0420A	SCREW (4x20)	1						
75	314506-6100A	CARBURETOR ASS'Y	1						Fig. C-1
76	314501-6131A	GASKET	1						
77	314599-6181A	INSULATOR	1						
78	314501-6184A	GASKET	2						
79	233B0525	SCREW (5x25)	3						
80	311B0600	NUT (6mm)	2						
81	411B0600	WASHER	2						
82	171G0620	STUD	2						
83	314506-6610A	FUEL TANK ASS'Y	1						
84	315515-6640A	•CAP, tank	1						


Ref.No.	Part No.	Part Name	Quantity						Remarks
			05A						
85	314401-6643E	••GASKET	1						
86	314401-6644A	••SPRING	1						
87	314401-6732A	••SCREW	2						
88	314506-6711A	BRACKET, tank	1						
89	311B0800A	NUT (8mm)	3						
90	411B0800	WASHER	3						
91	112B0612	BOLT (6x12)	1						
92	314501-6681A	WASHER	1						
93	314401-7411A	GAUGE, oil	2						
94	670B2015	O-RING	2						
95	314501-8111A	FLYWHEEL	1						
96	314501-8103A	IGNITION COIL ASS'Y	1						
97	314501-8123A	•COIL, ignition	1						
98	314401-8436A	•CONDENSER	1						
99	315501-8440A	•BREAKER, contact	1						
100	314401-8142A	BRUSH	1						
101	314401-8129A	CLAMP	1						
102	314501-8137A	BRACKET	1						
103	314501-8172A	COVER, breaker	1						
104	314501-8414A	RING	1						
105	131B0510	BOLT (5x10)	1						
106	131B0520	BOLT (5x20)	2						
107	241B0408	SCREW (4x8)	3						
108	242B0410A	SCREW (4x10)	1						
109	314401-8164A	GROMMET	1						
110	315G1200	NUT (12mm)	1						
111	312750-2371-00	KEY	1						
112	314501-3482A	WASHER	1						
113	314401-8410A	PLUG, spark (NGK BM6A)	1						
114	317270-8418B	CAP, plug	1						
115	317270-8419A	SPRING	1						
116	314401-8511B	SWITCH, stop	1						
117	314501-0811A	LABEL, mark	1						★★
118	314584-0817A	LABEL	1						★★
119	314584-0827A	LABEL	1						★★
120	314584-0851A	LABEL	1						★★



Ref.No.	Part No.	Part Name	Quantity						Remarks
			06A						
1	314501-1111A	HEAD, cylinder	1						
2	314501-1121A	GASKET, head	1						
3	186G0640	BOLT (6x40)	8						
4	314501-1231B	COVER, inspection	1						
5	314501-1232A	GASKET	1						
6	186B0612	BOLT (6x12)	3						
7	314506-1321A	COVER, air cleaner	1						
8	314595-1312A	ELEMENT	1						
9	314595-1313A	PLATE, air cleaner	1						
10	314506-1311A	CASE, air cleaner	1						
11	314413-1316A	BOLT	2						
12	314501-1332A	GASKET	1						
13	702A071000	TUBE, rubber	1						ℓ=140mm
14	314401-1341A	PIPE	1						
15	314504-1410A	MUFFLER ASS'Y	1						
16	395000-1442A	GASKET	1						
17	311120-1484-00	NUT	1						
18	171G0616	STUD	2						
19	311B0600	NUT (6mm)	1						
20	410B0600	WASHER	2						
21	314506-1611A	CASE, spiral	1						
22	186B0610	BOLT (6x10)	4						
23	314584-1631A	COVER, cylinder head	1						
24	314501-1632A	COVER, cylinder	1						
25	241B0510	SCREW (5x10)	1						
26	314501-2110A	VALVE, inlet	1						
27	314501-2112A	VALVE, exhaust	1						
28	314501-2113A	SPRING, valve	2						
29	314501-2116A	SEAT, spring	2						
30	314501-2211A	TAPPET	2						
31	314501-2311B	GEAR, cam	1						
32	314501-3111A	PISTON	1						
33	314598-3010B	PISTON RING SET	1						
34	314501-3121A	PIN, piston	1						
35	314501-3122A	RING, snap	2						
36	314598-3211A	SHAFT, crank	1						
37	314501-3240A	CONNECTING ROD ASS'Y	1						
38	314501-3245A	•BOLT, connecting rod	2						
39	314501-3248A	WASHER, lock	1						
40	314501-3249A	ARM, splash	1						
41	314501-3430A	RECOIL STARTER ASS'Y	1						Fig. R-1
42	314599-1650A	SCREEN	1						


Ref.No.	Part No.	Part Name	Quantity					Remarks
			06A					
43	187B0610	BOLT (6x10)	3					
44	314501-4110D	CRANK CASE ASS'Y	1					
45	314501-4211B	●BEARING, plain	1					
46	3145V2-7214A	●GASKET	2					
47	130B1014	●BOLT (10x14)	2					
48	314501-4231A	SEAL, oil	1					
49	551A0612	PIN, dowel	2					
50	314501-4120A	SIDE BASE ASS'Y	1					
51	314501-4211B	●BEARING, plain	1					
52	314501-4124A	GASKET	1					
53	186B0622	BOLT (6x22)	6					
54	314501-4231A	SEAL, oil	1					
55	314502-5110A	GOVERNOR ASS'Y	1					
56	314401-5121A	SLEEVE, governor	1					
57	314501-5122C	TIP, governor	1					
58	554A0600	PIN, snap	1					
59	410B0600	WASHER	1					
60	314401-5135A	WASHER	1					
61	314598-5211C	ARM, governor	1					
62	112B0625	BOLT (6x25)	1					
63	311B0600	NUT (6mm)	1					
64	411B0600	WASHER	1					
65	314501-5231A	LINK, governor	1					
66	314501-5232A	SPRING, link	1					
67	314502-5314A	SPRING, governor	1					
68	314501-5311A	LEVER, control	1					
69	314501-5335B	BRACKET	1					
70	314501-5389A	PLATE	1					
71	314401-5383A	WASHER	1					
72	314401-5385A	NUT	1					
73	314401-5388A	SPRING	1					
74	314401-5321B	SPRING	1					
75	214B0420A	SCREW (4x20)	1					
76	314506-6100A	CARBURETOR ASS'Y	1					Fig. C-1
77	314501-6131A	GASKET	1					
78	314599-6181A	INSULATOR	1					
79	314501-6184A	GASKET	2					
80	233B0525	SCREW (5x25)	3					
81	311B0600	NUT (6mm)	2					
82	411B0600	WASHER	2					
83	171G0620	STUD	2					
84	314506-6610A	FUEL TANK ASS'Y	1					

Ref.No.	Part No.	Part Name	Quantity					Remarks
			06A					
85	315515-6640A	●CAP, tank	1					
86	314401-6643E	●●GASKET	1					
87	314401-6644A	●●SPRING	1					
88	314401-6732A	●●SCREW	2					
89	314506-6711A	BRACKET, tank	1					
90	311B0800A	NUT (8mm)	3					
91	411B0800	WASHER	3					
92	112B0612	BOLT (6x12)	1					
93	314501-6681A	WASHER	1					
94	314401-7411A	GAUGE, oil	2					
95	670B2015	O-RING	2					
96	314501-8111A	FLYWHEEL	1					
97	314501-8103A	IGNITION COIL ASS'Y	1					
98	314501-8123A	●COIL, ignition	1					
99	314401-8436A	●CONDENSER	1					
100	315501-8440A	●BREAKER, contact	1					
101	314401-8142A	BRUSH	1					
102	314401-8129A	CLAMP	1					
103	314501-8137A	BRACKET	1					
104	314501-8172A	COVER, breaker	1					
105	314501-8414A	RING	1					
106	131B0510	BOLT (5x10)	1					
107	131B0520	BOLT (5x20)	2					
108	241B0408	SCREW (4x8)	3					
109	242B0410A	SCREW (4x10)	1					
110	314401-8164A	GROMMET	1					
111	315G1200	NUT (12mm)	1					
112	312750-2371-00	KEY	1					
113	314501-3482A	WASHER	1					
114	314401-8410A	PLUG, spark (NGK BM6A)	1					
115	317270-8418B	CAP, plug	1					
116	317270-8419A	SPRING	1					
117	314401-8511B	SWITCH, stop	1					
118	314501-0811A	LABEL, mark	1					★★
119	314584-0817A	LABEL	1					★★
120	314584-0827A	LABEL	1					★★
121	314584-0851A	LABEL	1					★★

Fig. C-1 CARBURETOR

Ref.No.	Part No.	Part Name	Quantity						Remarks
			06A						
	314506-6100A	CARBURETOR ASS'Y	1						
C-1- 1	314501-6139B	•SHAFT, throttle	1						
C-1- 2	314401-6115B	•SCREW, adjust	1						
C-1- 3	311509-6117-00	•SPRING	1						
C-1- 4	314401-6114A	•SCREW, slow stop	1						
C-1- 5	314401-6116A	•SPRING	1						
C-1- 6	314501-6142B	•SHAFT, choke	1						
C-1- 7	314501-6177A	•O-RING	1						
C-1- 8	314401-6164A	•SPRING	1						
C-1- 9	314401-6167A	•CAP, spring	1						
C-1-10	314501-6160B	•DIAPHRAGM	1						
C-1-11	314501-6171B	•GASKET	1						
C-1-12	314501-6143A	•SCREW	2						
C-1-13	314501-6147A	•WASHER	2						
C-1-14	311178-6132-10	•JET, main (#54)	1						
C-1-15	312801-6168A	•STRAINER	1						

Fig. R-1 RECOIL STARTER



Ref.No.	Part No.	Part Name	Quantity						Remarks
			06A						
	314501-3430A	RECOIL STARTER ASS'Y	1						
R-1- 1	3145V1-3432A	PULLEY	1						
R-1- 2	314501-3447A	BOLT	1						
R-1- 3	314401-3449A	RETAINER	1						
R-1- 4	314401-3446A	SPRING	1						
R-1- 5	314401-3445A	PAWL, recoil	1						
R-1- 6	314401-3444A	SPRING, return	1						
R-1- 7	314501-3441A	REEL, recoil	1						
R-1- 8	314401-3452A	SPRING, recoil	1						
R-1- 9	3145V1-3453A	ROPE (4x1120)	1						
R-1-10	312801-3454A	HANDLE, recoil starter	1						
R-1-11	314501-3437A	CASE, recoil starter	1						